


REPORT DOCUMENTATION PAGE

Form Approved
OMB No. 0704-0188

Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302, and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188), Washington, DC 20503.

1. AGENCY USE ONLY (Leave blank)		2. REPORT DATE 30 Jan 95		3. REPORT TYPE AND DATES COVERED Final, 1/10/94-30/1/95	
4. TITLE AND SUBTITLE High Power Switch Design				5. FUNDING NUMBERS N60921-94-C-A345	
6. AUTHOR(S) David V. Turnquist Brian W. Wegner				8. PERFORMING ORGANIZATION REPORT NUMBER G610FINL.TPM	
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) Central Connecticut Engineering, Inc. Unit A-4, 1275 Cromwell Ave. Rocky Hill, CT 06067					
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES) Dahlgren Division, Naval Surface Warfare Center 17320 Dahlgren Rd. Dahlgren, VA 22448-5100					
11. SUPPLEMENTARY NOTES				DTIC QUALITY INSPECTED 2	
12a. DISTRIBUTION/AVAILABILITY STATEMENT Approved for public release; SBIR report , distribution unlimited.				12b. DISTRIBUTION CODE 19950301 090	
13. ABSTRACT (Maximum 200 words) The complete manufacturing design of a high-power, high-repetition-rate switch has been developed. The switch will be capable of continuous operation at 100,000 volts, 100 kilowatts of average power, 100 joules per pulse, and 1000 hertz pulse repetition rates into a low impedance load. The inductance is minimized, as far as consistent with the other requirements, and the switch is designed for long life. The switch is a trigatron type spark gap with a high-pressure hydrogen-gas fill. The design is based directly on previous development of such devices by NSWCDD. The design includes an integrated fluid cooling system and a 100 kV, 1000 Hz trigger system. The design is capable of scaling to higher voltages and power levels. The manufactured switch will be vacuum sealed, and is designed to meet both military and commercial shock, vibration, temperature, and other environmental conditions.					
14. SUBJECT TERMS Triggered spark gap, High-voltage switch, Pulsed-power switch				15. NUMBER OF PAGES 161	
				16. PRICE CODE	
17. SECURITY CLASSIFICATION OF REPORT UNCLASSIFIED	18. SECURITY CLASSIFICATION OF THIS PAGE UNCLASSIFIED	19. SECURITY CLASSIFICATION OF ABSTRACT UNCLASSIFIED	20. LIMITATION OF ABSTRACT UL		

**FINAL TECHNICAL REPORT
IN ACCORDANCE WITH CDRL A001
CONTRACT N60921-94-C-A345**

**BY
CENTRAL CONNECTICUT ENGINEERING, INC.
UNIT A-4, 1275 CROMWELL AVE.
ROCK HILL, CT 06067
JANUARY 31, 1995**

Accession For	
NTIS CRA&I	<input checked="checked" type="checkbox"/>
DTIC TAB	<input type="checkbox"/>
Unannounced	<input type="checkbox"/>
Justification	
By	
Distribution/	
Availability Codes	
Dist	Avail and/or Special
A-1	

1. INTRODUCTION

This final report is submitted by Central Connecticut Engineering, Inc. in accordance with CDRL A001, Contract number N60921-94-C-A345, for research and development of a High Power Switch. The switch is a triggered spark gap with the following requirements:

High voltage hold-off of 100 kV

Pulse repetition rate of 1000 Hz

Energy per pulse of 100 J into a low impedance load

Average power switched of 100 kW

To meet these requirements a high-pressure trigatron-type spark gap has been designed in accordance with previous designs by NSWC, along with a trigger generator. The status of the project is described in the following sections.

The spark gap overall design is shown in drawing G610 and critical dimensions in drawing INSLSTR.

2. ELECTRODES

At the beginning of the project a meeting was held at NSWC to discuss the basic requirements and earlier work on the device. NSWC provided further published work and hydrogen breakdown data. At that time it was decided that the optimum E-E spacing might be near to 0.25 inches with trigger to adjacent electrode spacing of 0.16 inches, and with operating pressures of 400 to 500 PSI. Some of the breakdown data were re-plotted along with data taken from Meek & Craggs book on gas breakdown. The results are shown in Figure 1. The NSWC data shows some scatter but is in fairly good agreement with the Meek & Craggs information. In Fig. 1 the data is extrapolated to higher voltages. With an E-E spacing of 0.25", the SBV at 400 PSI is about 210 kV, and at 500 PSI is about 270 kV. These figures appear to be suitable for 100 kV high PRR operation.

These dimensions were used in the design of the spark gap, shown in Drawings G610, G610-xxx, A610-yyy, and the corresponding drawings for the de-mountable version.

Both the main electrodes and are to made of Tungsten matrix/Copper material - Metallwerk Plansee K25 or equivalent.

The trigger electrode tip uses Tungsten with a small percentage of Rhenium to improve its mechanical properties. The trigger electrode tip is 0.125" dia., brazed into a 1/4" copper support rod coaxial with the trigger insulator. In the demountable gap




FIGURE 1

version a copper extender is used. The design as shown requires a braze, for good thermal contact. The extender could be threaded for ease in replacement if needed.

The main electrodes have a flat diameter of 2.3", with the dimension driven outward by the cooling channel needs. The outer radius of the electrodes is 0.55", slightly more than twice the E-E space. This radius has been found in the past to offer a reasonably close approximation to a Rogowski shape, with minimal field enhancement at the beginning of the curvature.

The main electrodes are to be brazed with their inner copper cooling structures to the steel support plates and outer envelope structures.

All of the braze joints are shielded from exposure to the main arc, or from an area where an accidental breakdown might occur. This precaution is necessary since the gold/silver/copper braze alloys have a low vaporization temperature and, if struck by an arc, may easily contaminate the insulators.

The E-E spacing may be easily altered by changing a spacer behind the opposite electrode. As shown the spacer is about 1/8".

3. ENVELOPE AND HIGH PRESSURE CONSIDERATIONS

3.1 STEEL ENVELOPE

While the E-E spacing is designed for internal pressures of less than 500 PSI, the envelope design considered an internal pressure of 1000 PSI. This was done to accommodate some over-pressure during operation - although the active cooling should prevent gross over-heating, and pressure surges during a fault.

The material to be used for the outer envelope - the pressure containment - is 304 stainless steel. (It is also important to avoid magnetic materials.) As a consequence most of the brazing operations will require a very dry hydrogen furnace (not a significant problem for any vacuum-tube-grade manufacturer).

The inner diameter of the envelope was determined by the outer diameter of the main electrodes and the clearing to the wall. An annular spacing of 0.55 inches was selected, giving a minimum envelope ID of 4.5".

Both deflection and distortion of the end plates and the outer cylinder were calculated for a variety of diameters and thicknesses. Rourke's formulas for stress and strain were used. A yield strength of 30,000 PSI was used. The result was a choice of 3/4" thickness generally, operated at 8% of yield in the worst case, the plate at the high voltage insulator end of the gap.

3.2 INSULATOR SEALS

The most difficult problem posed by the high internal pressure is that of the ceramic-metal seals. The ceramic to be used is 94% Alumina (Wesgo AL-500 or equivalent). The ceramic itself is quite strong, especially if used in compression - over 300,000 PSI strength. In tension or flexure the strength is about 40,000 to 50,000 PSI, but since the material is very brittle it may be easily shattered by a localized stress concentration or flaw. The seals structures also require fairly thin metal at the seal since a perfect thermal match is never quite possible, even with the use of Kovar or Nickel/Iron 42 alloy. The result is that the ceramic diameter should be as small as possible to minimize the total shear force applied to the ceramic seal metal OD. A further worry is that the braze operation may weaken the metal by inter-granular penetration, or a change in the crystal structure.

For the main insulator a 2" nominal diameter was chosen, with tapered seals. The tapered seal - at about 15 degrees - is one of the strongest. Here the insulator is used so that the seals are put under further compression by the internal pressure of the spark gap. Very thick seal metal, 0.062, is used, but may be worked at up to 20% yield in the worst case (less than 10% at nominal).

The trigger ceramic nominal diameter is much smaller, only 3/4", and poses much less of a problem. Ordinary coaxial compression seals are used, operating at moderate stress levels.

3.3 DEMOUNTABLE STRUCTURE

A demountable version of the same structure is shown in drawing G611 and associated G611-xxx and A611-yyy drawings. The gap is assembled in three sub-assemblies:

Opposite electrode and main insulator

Adjacent electrode and steel enclosure

Trigger assembly

The sub-assemblies are joined by the use of Varian-type Conflat flanges with copper seals.

The same trigger insulator structure is used, and a trigger support extender is used to accommodate the Conflat flange and still leave room for the cooling plumbing.

4. COOLING

Heat dissipation in high pressure spark gaps is known to be significant, and an important task of the design has been the inclusion of a means of cooling in the unit. Energy loss has been the topic of considerable recent investigation by T. Martin and others at SNL, in particular. We have used his results, with the help of L. Rinehart and discussions with T. Martin, to estimate power dissipation in the switch. The Martin estimates, which so far seem to be borne out experiment, predict an energy loss proportional to $V_{peak} \times I_{peak}$ to the power of 1.1846. Extrapolating his curves to the case here, with 100 joules/pulse at 1000 Hz, we have the following result:

Peak voltage, kilovolts	100	100	100	100
Total load + PFN impedance	50	25	10	1.7
Peak current, kiloamps	2	4	10	59
$V_{peak} \times I_{peak}$, 10Exp9VA	0.2	0.4	1	5.9
Pulse width, nanoseconds	500	250	100	17
Average power, kilowatts	100	100	100	100
Loss, Kilowatts	0.87	2	5.9	48
Loss, Percent	1%	2%	6%	48%

A major unknown factor at this point is the distribution of power dissipation within the spark gap. T. Martin estimates approximately 1/3 of the total dissipation is deposited in the electrodes, the gas, and the outer wall, provided that we avoid conditions with extremely fast rise times. For the geometry of the G610 design we might expect that a significant portion of the gas dissipation also ends up in the electrodes. Altogether we now expect the power distribution to be fairly well distributed over the electrode surfaces, in the flat region of the main gap.

The initial assumption is that the cooling medium is water, and we have considered the case of about 5-6 kW of dissipation as the median design criterion. It is relatively easy to provide enough water to handle the total heat load - 6 kW only needs a flow rate the order of 1 GPM. This is handled easily with 1/4" plumbing channels. Conduction away from the electrode is a more serious problem. To couple the heat into the water requires that heat be conducted to a large portion of the water channel wall area. But even with OFHC copper, the heat conductivity is only 3.9 Watts per cm-degK, so a 1 cm cube of copper can conduct only 390 Watts if the temperature drop is constrained to 100 degK. The dimensions of the electrodes in the vicinity of the trigger are

of the order of only a few cm. After consideration of different water channel shapes, sizes, and locations, the configuration shown in G610 was arrived at. We estimate that the water channels shown can handle up to 2 kW even if the heat is concentrated, and 4-5 kW if there is some spreading by gas expansion and radiation.

More heat may be removed if the coolant is changed. There are several good but often very expensive cooling fluids. The best option that we have found at this time is Polydimethylsiloxane, manufactured by Dow with the name Syltherm XLT. This fluid is chemically inert, has a high electrical resistivity, has a viscosity not too much greater than water. Its density is 0.85, and its specific heat is about 2 J/gram/deg K. The same pumps, heat exchangers, valves, etc. used for water can handle this liquid. At the same time its operating temperature limits are much higher - it can be used at up to 260 deg C. The use of this material should significantly extend the operating power limits.

To provide both cooling and to collect heat dissipation data a fluid cooling system has been designed. Both a diagram and the basic bill of materials is attached. The pump is capable of high flow rate, and the system can be readily extended to higher power by changing the heat exchanger. The insulating portion of the plumbing uses Impolene, a high-temperature, inert, high-resistivity tubing, and the metal parts are all stainless steel. Temperature and flow metering, and flow control, are all included.

5. EXTERNAL CONNECTIONS AND INDUCTANCE

The high internal pressure leads to the use of a relatively small insulator diameter - 1.8 inches on the outside of the gap. A three inch length has been used to give an effective creepage path of a little over three inches, or a little less than 33 kV per inch. It is assumed that the unit will be operated in oil (or some dielectric fluid). A rule of 50 kV/inch maximum surface stress is used.

It is also assumed that a coaxial current return structure is also to be used. If the outer conductor (not shown in the G610 drawing) is 4 inches ID, the average radial stress is of the order of 57 kV/inch, and the maximum stress on the inner cylinder is 197 kV/inch, a high stress, about 20% of the maximum stress on good, clean oil. A concentric barrier sleeve - Mylar, Teflon, or Polycarbonate - around the inner conductor, just inside the main insulator ID, seems called for.

The estimated total inductance of the switch itself is approximately 100 nH, higher than hoped for. 75 to 80%, or about 80 nH, is associated with the main insulator and opposite electrode conductor.

Removing one flute of the inner portion of the insulator might yield 12 nH if this factor should prove critical. A safer alternative would be to remove an inch of the length of the outer portion of the insulator, and about 15 nH. Electric field stress problems on the outside might then be addressed with the use of plastic sleeves and barriers, which may be needed anyway.

6. SPARK GAP PROCESSING AND ASSEMBLY

The required process specifications are given in the attached drawings P-xxx. These include the pump processing procedures. A set of process flow charts specify the appropriate use of the cleaning, plating, assembly, and pump requirements.

A description of the required pump processing station is also appended.

7. TRIGGER GENERATOR

The schematic of the trigger generator is shown in ST610-1.

In order to achieve long-term reliable operation at high repetition rates a hydrogen thyatron is used. The thyatron type chosen is used in excimer and CO2 laser circuits with high charge transfer rates and high peak currents, but, nevertheless, is not capable of switching in less than 20 nanoseconds.

The thyatron is to operate at 20 to 25 kV, with a maximum capability of 32 kV. The step-up transformer will be designed for 1:4 ratio to provide a 100 kV output. The basic design assumes that a faster rise time pulse will be needed, and so a combination of a high-voltage storage cap of 20 pF and a sharpening gap is used at the output. The sharpening gap is also to be built with a high pressure hydrogen fill. This unit will allow fairly easy experimentation with rise rates, trigger voltages, and available energy. A design for such a gap is shown in drawing OV610-01.

The pulse transformer will be a low inductance metglass core unit.

The internal energy storage capacitors total 5 nF, giving an energy of over 1 J/pulse available. At one kHz the unit will provide over 1 kW of trigger power.

The unit provides voltage monitoring, a safety dump and trigger inhibit, external access to a latching safety interlock circuit, and emergency shutdown. The relay logic uses a standard C.C.E. latching relay card.

The thyatron driver and driver interlock are shown in drawings ST610-2, -3, -4, -5, and -6.



The power transformer and charging choke will be specified and bought as special purpose items.

The trigger generator is to be built in two sections:

A rack mounted enclosure will contain the controls, thyatron driver, and high voltage supply. The enclosure panel design is shown in drawings MDT610-20 and -21.



The thyatron, HV PFN caps, pulse transformer, and sharpening gap are to be built in a coaxial housing, which will then bolt directly onto the gap's trigger assembly. This step is taken to provide minimum trigger inductance and maximum rate of rise of trigger voltage. The coax housing diameter will be approximately 4 1/4 inches.

SPARK GAP PARTS





REFERENCE ONLY		DATE		C. C. E., INC.	
UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES DIMENSIONS IN PARENTHESES METRIC (mm) ARE IN PARENTHESES		DRAWN		G 610	
TOLERANCES OF FRACTIONS 31/64		CHKD		TRIGGERED SPARK GAP	
TOLERANCES OF DECIMALS		APPD		HIGH PRESSURE HYDROGEN	
X .001 X .0005 X .001				CAGE CODE	
X .001 X .0005 X .001				DRAWING NO.	
X .001 X .0005 X .001				G0610	
X .001 X .0005 X .001				REV	
X .001 X .0005 X .001				A	
X .001 X .0005 X .001				SHEET	
X .001 X .0005 X .001				OF	
X .001 X .0005 X .001				CONTRACT/JOB NUMBER	
X .001 X .0005 X .001				SCALE	
X .001 X .0005 X .001				WEIGHT	
X .001 X .0005 X .001				APPLICATION	

REV	DESCRIPTION	DATE	APVD



REFERENCE ONLY	UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES METRIC DIMS ARE IN PARENTHESES	DATE	C. C. E., INC.
	TOLERANCES OF FRACTIONS 24/64		G 610
	TOLERANCES OF DECIMALS		INSULATOR STRUCTURE
	1. BREAK EDGES 1/64 MAX		CASE CODE DRAWING NO.
	2. DO NOT SCALE THIS DRAWING		02887
	3. DIMENSIONS TO ANGLES 1/16 1/32 1/64		SCALE
	4. MAX. ALL MACHINED SURFACES		WEIGHT
PART NOT NEXT ASSY.	USED IN	CONTRACT/JOB NUMBER	INSLSR
APPLICATION			REV
			A
			SHEET
			OF

REV	DESCRIPTION	DATE	APVD




NOTES:
 DIAMETERS A & B CONCENTRIC 0.010 MAX TIR
 SURFACES S & T PERPENDICULAR TO DIA B TO 0.005 TIR
 RADIUS TO BLEND SMOOTHLY

MATERIAL: TUNGSTEN 75% COPPER 25% (K25 OR EQUIV.)

REFERENCE ONLY	DATE	C. C. E., INC.
ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN INCHES	DATE	G 610
METRIC DIMENSIONS ARE IN PARENTHESES	DATE	OPPOSITE MAIN ELECTRODE
TOLERANCES IF FRACTIONS 1/64	DATE	OPPOSITE MAIN ELECTRODE
TOLERANCES IF DECIMALS	DATE	OPPOSITE MAIN ELECTRODE
X 4001 XX 40005 (403)	DATE	OPPOSITE MAIN ELECTRODE
1. BREAK EDGE 1/64 MAX	DATE	OPPOSITE MAIN ELECTRODE
2. DIM NOT SCALE THIS DRAWING	DATE	OPPOSITE MAIN ELECTRODE
3. DIMENSION TO ANSI 11A3.1982	DATE	OPPOSITE MAIN ELECTRODE
4. MAX. ALL MACHINED SURFACES	DATE	OPPOSITE MAIN ELECTRODE
PART NOT TEST ASSY. USED IN	DATE	OPPOSITE MAIN ELECTRODE
APPLICATION	DATE	OPPOSITE MAIN ELECTRODE
CONTRACT/JOB NUMBER	DATE	OPPOSITE MAIN ELECTRODE
SCALE	DATE	OPPOSITE MAIN ELECTRODE
WEIGHT	DATE	OPPOSITE MAIN ELECTRODE
SHEET OF	DATE	OPPOSITE MAIN ELECTRODE

REV	DESCRIPTION	DATE	APV



NOTES:
 SURFACE S FLAT 0.005 TIR
 SURFACE S PERPENDICULAR TO DIA A & DIA B 0.005 TIR
 DIAS A & B CONCENTRIC 0.005 TIR
 SURFACE FINISH 32 MICROINCHES MAX
 MAXIMUM BURR 0.001


MATERIAL: 304 STAINLESS STEEL

C. C. E., INC.		DATE	
G 610		DRAWN	
SPACER		CHKD	
OPPOSITE ELECTRODE		APPD	
GAGE CODE 07887		CONTRACT/JOB NUMBER	
DRAWING NO. G610-005		SCALE	
REV A		WEIGHT	
SHEET 1 OF 1			

REFERENCE ONLY	UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES FRACTIONS ARE IN PARENTHESES TOLERANCES OF FRACTIONS 1/16
	TOLERANCES OF DECIMALS
	X .001 X .0005 X .002
	1. PRECISION 1/16 MAX
	2. DO NOT SCALE THIS DRAWING
	3. DIMENSION TO ANGLES 114.3 1982
	4. MAX. ALL MACHINED SURFACES

PART NO. NEXT ASSY. USED IN
 APPLICATION

REV	DESCRIPTION	DATE	APPROVED




NOTES:
 DIAMETERS A & B CONCENTRIC 0.005 TIR MAX
 SURFACES S & T PERPENDICULAR TO DIA B TO 0.005 TIR
 RADIUS TO BLEND SMOOTHLY
 MAXIMUM BURR 0.001
 SURFACE FINISH 32 MICROINCHES MAXIMUM

MATERIAL: 304 STAINLESS STEEL


REFERENCE ONLY		UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES METRIC (mm) ARE IN PARENTHESES	DRAWN DPR	DATE	C. C. E., INC.	
		TOLERANCES OF FRACTIONS 3/64			G 610	
		TOLERANCES OF DECIMALS			BACKING PLATE	
		1. BREAK EDGES 1/64 MAX			OPPOSITE ELECT COOLING	
		2. DIMENSIONS TO CENTER UNLESS OTHERWISE SPECIFIED			G610-0006	
		3. DIMENSION TO ANSI Y14.3 1982			REV A	
		4. HON. ALL MACHINED SURFACES			SHEET 1 OF 1	
PART NO. NEXT ASSY.	USED IN	CONTRACT/JOB NUMBER	SCALE	WEIGHT		
APPLICATION						

REV	DESCRIPTION	DATE	APPROVED



NOTES:
 DIAMETERS A & B CONCENTRIC 0.010 TIR MAX
 SURFACES S & T PERPENDICULAR TO DIA A TO 0.005 TIR
 RADIUS TO BLEND SMOOTHLY
 MAXIMUM BURR 0.001
 SURFACE FINISH 32 MICROINCHES MAXIMUM
 MATERIAL: OFHC COPPER


REFERENCE ONLY	UNLESS OTHERWISE SPECIFIED, ALL DIMENSIONS ARE IN INCHES. METRIC DIMS ARE IN PARENTHESES	DATE	C. C. E., INC.
	TOLERANCES OF FRACTIONS 21/64	DRAWN	G 610
	TOLERANCES OF DECIMALS	CHKD	COOLING CHANNEL
	1. BREAK EDGES 1/64 MAX	APPD	OPPOSITE ELECT COOLING
	2. DO NOT SCALE THIS DRAWING		
	3. DIMENSIONS ON THIS DRAWING		
	4. HIDE ALL MACHINED SURFACES		
PART NO. 1001 ASSY.		CONTRACT/JOB NUMBER	CAGE CODE 07887
APPLICATION			SCALE 1:1
			WEIGHT 6610-007
			SHEET 1 OF 1



MATERIAL: 304 STAINLESS STEEL

REFERENCE ONLY	DATE	C. C. E. INC.	
UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES METRIC GOVT ARE IN PARENTHESES	TRAVALIN TSPB APPO	G 610	REV B
TOLERANCES GO/FRACTIORS 41/64		ADJ BACKING PLATE	
TOLERANCES OF DIMENSIONS		ADJ ELECT COILING	
1. 4.0001			
2. BREAK EDGES 1/64 MAX			
3. DIMENSIONS TO ANG2 114.5 150R			
4. MAX. ALL MACHINED SURFACES.			
PART NO	CONTRACT/JOB NUMBER	CAGE CODE	BRANDING NO
REV. ASSY.		02887	G610-008
USED IN		SCALE	WEIGHT
			SHEET OF

REV	DESCRIPTION	DATE	APPROVED




NOTES
 DIAMETERS A, B, C, & D CONCENTRIC 0.005 MAX TIR
 SURFACES S & T PERPENDICULAR TO DIA B TO 0.005 TIR
 SURFACE FINISH 32 MICROINCHES MAX

MATERIAL: OFHC COPPER

REFERENCE ONLY		UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES METRIC (mm) ARE IN PARENTHESES		DATE		C. C. E., INC.	
TOLERANCES OF FRACTIONS 21/64		TOLERANCES OF DECIMALS		DRAWN		G 610	
.X .001		.XX .0005		CHKD		ADJ COOLING CHANNEL	
.XX .001		.XXX .0005		APPD		ADJACENT ELECT COOLING	
.XXX .001		.XXXX .0005					
.XXXX .001		.XXXXX .0005					
.XXXXX .001		.0005					
.0005							

REV	DESCRIPTION	DATE	APPROVED
1			




NOTES:
 1. DIAMETERS A AND B CONCENTRIC 0.002 TIR
 2. SURFACE S FLAT AND PERPENDICULAR TO DIA A 0.002 TIR
 3. SURFACE FINISH 32 MICROINCHES

C. C. E., INC.		DATE	
G 610		DRAWN	
TRIGGER ASSEM SPACER		CHKD	
		APPD	
		UNLESS OTHERWISE SPECIFIED	
		ALL DIMENSIONS ARE IN INCHES	
		METRIC DIMS ARE IN PARENTHESES	
		TOLERANCES OF FRACTIONS 21/64	
		TOLERANCES OF DECIMALS	
		XX ±0.01	XX ±0.005
		XX ±0.005	XX ±0.002
		1. BREAK EDGES 1/4" MAX	
		2. TO NOT SCALE THIS DRAWING	
		3. DIMENSIONS TO ANGLES 114.5 1982	
		4. MAX. ALL MACHINED SURFACES	
PART NO.	TRIG ASSEM	USED ON	
APPLICATION			
CAGE CODE	02887	DRAWING NO.	G610-011
SCALE		WEIGHT	
		SHEET	OF

MATERIAL: 304 STAINLESS STEEL

REV	DESCRIPTION	DATE	APPROVED




NOTES:
DIA'S B & C CONCENTRIC DIA A 0.010 TIR
SURFACE S FLAT AND PERPENDICULAR TO DIA A 0.002 TIR
SURFACE T PERPENDICULAR DIA A 0.002 TIR
INSIDE CORNER RADIUS 0.005 MAX

MATERIAL: 304 STAINLESS STEEL

REFERENCE ONLY	UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES METRIC (mm) ARE IN PARENTHESES	DATE	C. C. E., INC.
	TOLERANCES OF FRACTIONS 31/64		G 610
	TOLERANCES OF DECIMALS		END PLATE
	X .001 X .0005 X .003		MAIN INSL ASSEM
	1 BREAK EDGES 1/64 MAX		CAGE CODE DRAWING NO. G610-012
	2 MAX SURFACE FINISH 125		SCALE 0.2887
	3 DIMENSION TO AXIS UNLESS NOTED		WEIGHT
	4 MAX. ALL MACHINED SURFACES		SHEET OF
PART NO NEXT ASSY.	USED IN	CONTRACT/JOB NUMBER	REV
APPLICATION			B


REVISIONS		DATE	APPROVED
LTR	DESCRIPTION		



MATERIAL: TUNGSTEN + 3% RHENIUM, PLANSEE W3Re OR EQUIVALENT, 0.120 ROD

REFERENCE ONLY		UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES METRIC (mm) ARE IN PARENTHESES	DRAWN	DATE	C. C. E., INC.	
		TOLERANCES OF FRACTIONS AS/64	CHKD		G 610	
		TOLERANCES OF DECIMALS	APPD		TRIGGER PIN	
		X .001 X .0005 X .003				
		1. BREAK EDGES 1/64 MAX				
		2. DO NOT SCALE THIS DRAWING				
		3. DIMENSIONS TO ANST 114.5 1962				
		4. MAX. ALL MACHINED SURFACES				
PART NO	TEXT ASSY.	USED IN	CONTRACT/JOB NUMBER	CAGE CODE	DRAWING NO.	REV
				02887	G610-013	A
APPLICATION				SCALE	WEIGHT	SHEET OF

REVISIONS		DATE	APVD
LYR	DESCRIPTION		




MATERIAL 304 STAINLESS STEEL

REFERENCE ONLY		UNLESS OTHERWISE SPECIFIED, ALL DIMENSIONS ARE IN INCHES. METRIC DIMS ARE IN PARENTHESES.		DATE	
		TOLERANCES OF FRACTIONS 31/64		DRAWN	
		TOLERANCES OF DECIMALS		CHKD	
		X .4001 X .4008 X .003"		APPD	
		1. TREATMENT: V4A MAX			
		2. FINISH: SCALE THIS DRAWING			
		3. DIMENSIONS TO ANSI Y14.3 1982			
		4. HVAL. ALL MACHINED SURFACES.			
PART NO. NEXY ASSY.		TOLERANCE		CONTRACT/JOB NUMBER	
				GAGE CODE	
				07887	
				DRAWING NO.	
				G610-015	
				WEIGHT	
				SHEET OF	
				REV	
				A	


C. C. E., INC.
G 610
OUTER WATER TUBE
ASSEM A610-007

REVISIONS		DATE	APD
LTR	DESCRIPTION		




MATERIAL: 304 STAINLESS STEEL

UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES METRIC (mm) ARE IN PARENTHESES		DATE	DATE
TOLERANCES OF FRACTIONS 1/64		DRAWN	
TOLERANCES OF DECIMALS		CHKD	
X .001 X .0005 <.001		APPD	
1. BREAK EDGES 1/64 MAX		CONTRACT/JOB NUMBER	
2. DO NOT SCALE THIS DRAWING		SCALE	
3. DIMENSION TO ANSI Y14.5 1982		WEIGHT	
4. MAX. ALL MACHINED SURFACES		SHEET OF	
PART NO. NEXT ASSY.	USED IN	C. C. E. V. INC.	
APPLICATION		G 610	
		INNER WATER TUBE	
		ASSEM. A610-007	
		GAGE CODE 02887	
		DRAWING NO. G610-016	
		REV A	



MATERIAL: 42% NICKEL - BALANCE IRON
THICKNESS: 0.0625 ±0.002

REFERENCE ONLY	DATE	C. C. E., INC.	
IN THE DRAWING TO BE USED FOR THE MANUFACTURE OF THIS ITEM, THE FOLLOWING DIMENSIONS METRIC (mm) ARE IN PARENTHESES TOLERANCES OF FRACTIONS 24/64 APPLY	DRAWN CHKD APPD	G 610 SEAL FLANGE MAIN INSULATOR	
TOLERANCES OF DIMENSIONS			
1. FRACTION 1/64 MAX			
2. DECIMAL TO ANGLES 1/16 IN			
3. MAX. ALL SURFACES			
4. MAX. ALL SURFACES			
5. MAX. ALL SURFACES			
6. MAX. ALL SURFACES			
7. MAX. ALL SURFACES			
8. MAX. ALL SURFACES			
9. MAX. ALL SURFACES			
10. MAX. ALL SURFACES			
11. MAX. ALL SURFACES			
12. MAX. ALL SURFACES			
13. MAX. ALL SURFACES			
14. MAX. ALL SURFACES			
15. MAX. ALL SURFACES			
16. MAX. ALL SURFACES			
17. MAX. ALL SURFACES			
18. MAX. ALL SURFACES			
19. MAX. ALL SURFACES			
20. MAX. ALL SURFACES			
21. MAX. ALL SURFACES			
22. MAX. ALL SURFACES			
23. MAX. ALL SURFACES			
24. MAX. ALL SURFACES			
25. MAX. ALL SURFACES			
26. MAX. ALL SURFACES			
27. MAX. ALL SURFACES			
28. MAX. ALL SURFACES			
29. MAX. ALL SURFACES			
30. MAX. ALL SURFACES			
31. MAX. ALL SURFACES			
32. MAX. ALL SURFACES			
33. MAX. ALL SURFACES			
34. MAX. ALL SURFACES			
35. MAX. ALL SURFACES			
36. MAX. ALL SURFACES			
37. MAX. ALL SURFACES			
38. MAX. ALL SURFACES			
39. MAX. ALL SURFACES			
40. MAX. ALL SURFACES			
41. MAX. ALL SURFACES			
42. MAX. ALL SURFACES			
43. MAX. ALL SURFACES			
44. MAX. ALL SURFACES			
45. MAX. ALL SURFACES			
46. MAX. ALL SURFACES			
47. MAX. ALL SURFACES			
48. MAX. ALL SURFACES			
49. MAX. ALL SURFACES			
50. MAX. ALL SURFACES			
51. MAX. ALL SURFACES			
52. MAX. ALL SURFACES			
53. MAX. ALL SURFACES			
54. MAX. ALL SURFACES			
55. MAX. ALL SURFACES			
56. MAX. ALL SURFACES			
57. MAX. ALL SURFACES			
58. MAX. ALL SURFACES			
59. MAX. ALL SURFACES			
60. MAX. ALL SURFACES			
61. MAX. ALL SURFACES			
62. MAX. ALL SURFACES			
63. MAX. ALL SURFACES			
64. MAX. ALL SURFACES			
65. MAX. ALL SURFACES			
66. MAX. ALL SURFACES			
67. MAX. ALL SURFACES			
68. MAX. ALL SURFACES			
69. MAX. ALL SURFACES			
70. MAX. ALL SURFACES			
71. MAX. ALL SURFACES			
72. MAX. ALL SURFACES			
73. MAX. ALL SURFACES			
74. MAX. ALL SURFACES			
75. MAX. ALL SURFACES			
76. MAX. ALL SURFACES			
77. MAX. ALL SURFACES			
78. MAX. ALL SURFACES			
79. MAX. ALL SURFACES			
80. MAX. ALL SURFACES			
81. MAX. ALL SURFACES			
82. MAX. ALL SURFACES			
83. MAX. ALL SURFACES			
84. MAX. ALL SURFACES			
85. MAX. ALL SURFACES			
86. MAX. ALL SURFACES			
87. MAX. ALL SURFACES			
88. MAX. ALL SURFACES			
89. MAX. ALL SURFACES			
90. MAX. ALL SURFACES			
91. MAX. ALL SURFACES			
92. MAX. ALL SURFACES			
93. MAX. ALL SURFACES			
94. MAX. ALL SURFACES			
95. MAX. ALL SURFACES			
96. MAX. ALL SURFACES			
97. MAX. ALL SURFACES			
98. MAX. ALL SURFACES			
99. MAX. ALL SURFACES			
100. MAX. ALL SURFACES			
101. MAX. ALL SURFACES			
102. MAX. ALL SURFACES			
103. MAX. ALL SURFACES			
104. MAX. ALL SURFACES			
105. MAX. ALL SURFACES			
106. MAX. ALL SURFACES			
107. MAX. ALL SURFACES			
108. MAX. ALL SURFACES			
109. MAX. ALL SURFACES			
110. MAX. ALL SURFACES			
111. MAX. ALL SURFACES			
112. MAX. ALL SURFACES			
113. MAX. ALL SURFACES			
114. MAX. ALL SURFACES			
115. MAX. ALL SURFACES			
116. MAX. ALL SURFACES			
117. MAX. ALL SURFACES			
118. MAX. ALL SURFACES			
119. MAX. ALL SURFACES			
120. MAX. ALL SURFACES			
121. MAX. ALL SURFACES			
122. MAX. ALL SURFACES			




DASH #	DIA A	WIRE D	MATERIAL	LIG/SOLID DEG C
001	2 17/64	1/32	DFHC COPPER	1083/1083
002	3 25/64	1/32	DFHC COPPER	1083/1083
003	1/2	1/32	PALCUSIL 15	900/850
004	1/2	1/32	DFHC COPPER	1083/1083
005	1/4	1/32	DFHC COPPER	1083/1083
006	1/8	1/32	PALCUSIL 15	900/850
007	1/4	1/32	PALCUSIL 15	900/850

REFERENCE ONLY		UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES METRIC (mm) ARE IN PARENTHESES		DATE	
		TOLERANCES OF FRACTIONS 31/64		DRAWN	
		TOLERANCES OF DECIMALS		CHKD	
		.X .001 .XX .0005 <.005>		APPD	
		1. BREAK EDGES 1/4" MAX		CONTRACT/JOB NUMBER	
		2. DO NOT SCALE THIS DRAWING		SCALE	
		3. DIMENSION TO ANGLES VIALS 1982		WEIGHT	
		4. MAX. ALL MACHINED SURFACES		SHEET OF	
PART NOT TESTED ASST. USED IN		APPLICATION		C. C. E., INC.	
				G 610	
				SOLDER/BRAZE RINGS	
				CASE CODE 02887	
				DRAWING NO. B6-1	
				REV. A	

SWAGELOK to Tube Socket Weld Union

DIMENSIONS —
A-C-D are typical finger-tight.
F-G are across hex flats.




CONNECTS TUBES

T Tube O.D.	CATALOG NUMBER	A	B	Bx	C	D	E Minimum Opening	F	G	H	J
1/8	-200-6-2W	1.14	.34	.25	.60	.50	.09	7/16	7/16	.88	.31
1/4	-400-6-4W	1.32	.41	.31	.70	.60	.19	1/2	9/16	1.03	.44
3/8	-600-6-6W	1.48	.47	.38	.76	.66	.28	5/8	1 1/16	1.19	.62
1/2	-810-6-8W	1.62	.47	.50	.86	.90	.41	13/16	7/8	1.22	.75
3/4	-1210-6-12W	1.71	.47	.56	.86	.96	.62	1 1/16	1 1/8	1.31	1.05
1	-1610-6-16W	2.07	.56	.75	1.04	1.23	.88	1 3/8	1 1/2	1.59	1.31

SWAGELOK to Tube Socket Weld Elbow

DIMENSIONS —
A-C-D are typical finger-tight.
F is across wrench pads.
G is across hex flats.




CONNECTS TUBES

T Tube O.D.	CATALOG NUMBER	A	A ₁	Bx	C	D	E Minimum Opening	F	F ₁	G	Hx	Hx ₁	Hy	Hy ₁	K	K ₁
1/4	-400-9-4W†	1.06	1.01	.31	.70	.60	.19	1/2	7/16	9/16	.77	.72	.77	.72	.50	.50
3/8	-600-9-6W†	1.20	1.13	.38	.76	.66	.28	5/8	1/2	1 1/16	.91	.84	.91	.84	.62	.62
1/2	-810-9-8W†	1.42	1.37	.50	.86	.90	.41	13/16	1 1/16	7/8	1.02	.97	1.02	.97	.81	.81

SWAGELOK to Male Pipe Weld Connector

DIMENSIONS —
A-C-D are typical finger-tight.
F-G are across hex flats.




CONNECTS TUBE TO PIPE

T Tube O.D.	Male Pipe Weld Size	CATALOG NUMBER	A	B	C	D	E Minimum Opening	F	G	H	J
1/8	1/8	-200-1-2W	1.20	.38	.60	.50	.09*	7/16	7/16	.94	.405
3/16	3/16	-300-1-2W	1.23	.38	.63	.54	.12*	7/16	1/2	.97	.405
1/4	1/4	-400-1-2W	1.29	.38	.70	.60	.19	1/2	9/16	1.00	.405
1/4	1/4	-400-1-4W	1.49	.56	.70	.60	.19*	9/16	9/16	1.20	.540
5/16	5/16	-500-1-2W	1.34	.38	.73	.64	.20	9/16	5/8	1.05	.405
5/16	1/4	-500-1-4W	1.52	.56	.73	.64	.25	9/16	5/8	1.23	.540
3/8	1/4	-600-1-4W	1.57	.56	.76	.66	.28	5/8	1 1/16	1.28	.540
3/8	3/8	-600-1-6W	1.57	.56	.76	.66	.28*	1 1/16	1 1/16	1.28	.675
3/8	1/2	-600-1-8W	1.82	.75	.76	.66	.28*	7/8	1 1/16	1.53	.840
1/2	3/8	-810-1-6W	1.71	.56	.86	.90	.41	13/16	7/8	1.31	.675
1/2	1/2	-810-1-8W	1.93	.75	.86	.90	.41*	7/8	7/8	1.53	.840
1/2	3/4	-810-1-12W	1.99	.75	.86	.90	.41*	1 1/16	7/8	1.59	1.050
5/8	1/2	-1010-1-8W	1.93	.75	.86	.96	.50	15/16	1	1.53	.840
3/4	3/4	-1210-1-12W	1.99	.75	.86	.96	.62*	1 1/16	1 1/8	1.59	1.050
1	1	-1610-1-16W	2.45	.94	1.04	1.23	.88*	1 3/8	1 1/2	1.97	1.315

For tube O.D. sizes 1-1/4", 1-1/2" and 2", see *Tube Fittings Over 1"* subsection in your Master Catalog Binder.

SWAGELOK to Male Pipe Weld Elbow

DIMENSIONS —
A-C-D are typical finger-tight.
F is across wrench pads.
G is across hex flats.



CONNECTS TUBE TO PIPE


T Tube O.D.	Male Pipe Weld Size	CATALOG NUMBER	A	A ₁	B	C	D	E Minimum Opening	F	F ₁	G	Hx	Hx ₁	Hy	Hy ₁	J
1/4	1/8	-400-2-2W†	1.06	1.01	.38	.70	.60	.19*	1/2	7/16	9/16	.77	.72	.74	.75	.405
1/4	1/4	-400-2-4W	1.06	1.07	.56	.70	.60	.19*	1/2	1/2	9/16	.77	.78	.92	.94	.540
3/8	1/4	-600-2-4W†	1.20	1.13	.56	.76	.66	.28	5/8	1/2	1 1/16	.91	.84	1.00	1.00	.540
1/2	1/2	-810-2-8W	1.42	1.43	.75	.86	.90	.41*	13/16	13/16	7/8	1.02	1.03	1.30	1.38	.840
3/4	3/4	-1210-2-12W†	1.57	1.56	.75	.86	.96	.62*	1 1/16	1	1 1/8	1.17	1.16	1.45	1.50	1.050

* "E" dimension is minimum opening. Fittings of this group are back-drilled to larger I.D. at pipe weld end.
For more information on weld fittings, see *Weld Fittings* subsection in your Master Catalog Binder.

All dimensions are in inches. Dimensions for reference only, subject to change.
DIMENSIONS — A₁ - F₁ - Hx₁ - Hy₁ - K₁ are for brass and aluminum only / † Brass and aluminum fittings marked thus are not gageable.
When ordering, be sure to specify material. See pages 6 and 7 for complete ordering information.

SPARK GAP ASSEMBLIES

REVISIONS		DATE	APPROVED
LYR	DESCRIPTION		



REFERENCE ONLY		DATE	C. C. E., INC.	
		DATE	G 610	
		DATE	HV INSULATOR ASSEMBLY	
		DATE	CAGE CODE	
		DATE	DRAWING NO.	
		DATE	SCALE	
		DATE	CONTRACT / JOB NUMBER	
		DATE	REV	
		DATE	A610-001	
		DATE	SHEET	
		DATE	OF	


UNLESS OTHERWISE SPECIFIED
ALL DIMENSIONS ARE IN INCHES
METRIC DIMS ARE IN PARENTHESES
TOLERANCES OF FRACTIONS 41/64
TOLERANCES OF DECIMALS
X .001 X .0005 < .003
1. BREAK DIMS 1/64 MAX
2. DO NOT SCALE THIS DRAWING
3. DIMENSION TO ANGLES 114.5 1982
4. MAX. ALL MACHINED SURFACES

REVISIONS		DATE	APPROVED
LYR	DESCRIPTION		

G610-042



G610-003




G610-041



REFERENCE ONLY		DATE		C. C. E., INC.	
ALL DIMENSIONS ARE IN INCHES ALL DIMENSIONS ARE IN PARENTHESES METRIC DIMENSIONS ARE IN PARENTHESES		DRAWN		G 610	
TOLERANCES OF FRACTIONS 1/16		CHKD		HV INSULATOR ASSEMBLY	
TOLERANCES OF DECIMALS		APPD		EXPLODED VIEW	
X .001		X .0005		PAGE CODE	
X .0001		X .00005		DRAWING NO.	
X .00001		X .000005		02887	
X .000001		X .0000005		SCALE	
X .0000001		X .00000005		CONTRACT/JOB NUMBER	
X .00000001		X .000000005		REV	
X .000000001		X .0000000005		A	
X .0000000001		X .00000000005		6610-JEX	
X .00000000001		X .000000000005		SHEET	
X .000000000001		X .0000000000005		OF	
X .0000000000001		X .00000000000005		7	
X .00000000000001		X .000000000000005		PART NO. NEXT ASSY.	
X .000000000000001		X .0000000000000005		USED IN	
X .0000000000000001		X .00000000000000005		APPLICATION	


REV	DESCRIPTION	DATE	APPD



C. C. E., INC.		DATE	
G 610		DATE	
ELECT-INSUL ASSEMBLY		DATE	
BRAZED		DATE	
CAGE CODE 07887		DATE	
SCALE		DATE	
WEIGHT		DATE	
CONTRACT/ADD NUMBER		DATE	
REV		DATE	
A610-003		DATE	
SHEET		DATE	
OF		DATE	

REFERENCE ONLY	UNLESS OTHERWISE SPECIFIED
	ALL DIMENSIONS ARE IN INCHES
	FRACTIONS 1/16, 1/8, 1/4, 3/8, 1/2, 5/8, 3/4, 7/8
	TOLERANCES OF FINISHES 12/64
	TOLERANCES OF SURFACES
	1. BREAK EDGES 1/4" MAX
	2. DO NOT SCALE THIS DRAWING
	3. MAX. ALL MACHINED SURFACES
	4. MAX. ALL MACHINED SURFACES
	5. MAX. ALL MACHINED SURFACES
	6. MAX. ALL MACHINED SURFACES
	7. MAX. ALL MACHINED SURFACES
	8. MAX. ALL MACHINED SURFACES
	9. MAX. ALL MACHINED SURFACES
	10. MAX. ALL MACHINED SURFACES


REV	DESCRIPTION	DATE	BY
1			



NOTE:
EXHAUST TUBULATION, G610-016, AND
SOLDER RING B6-1-005 NOT SHOWN


REFERENCE ONLY		UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES METRIC (mm) ARE IN PARENTHESES	DRAWN	DATE	C. C. E., INC.	
		TOLERANCES OF FRACTIONS 31/64	CHKD		G 610	
		TOLERANCES OF DECIMALS	APPD		ENCLOSURE ASSEMBLY	
		1. BREAK EXERCISE 1/44 MAX			BRAZED	
		2. TO FIT SCALE THIS DRAWING			DRAWING NO.	
		3. DIMENSION TO ANGLES 1/44 1/8			02887	
		4. HATCH ALL MACHINED SURFACES			SCALE	
PART NOT IDENTIFIED	USED IN	CONTRACT/JOB NUMBER			REV	SHEET
					A610-005	A

REV	DESCRIPTION	DATE	APPROV




NOTE:
EXHAUST TUBULATION, G610-016, AND
BRAZE RING B6-1-005 NOT SHOWN

REFERENCE ONLY		UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES METRIC (mm) ARE IN PARENTHESES TOLERANCES OF FRACTIONS 31/64 TOLERANCES OF DECIMALS	DATE	C. C. E., INC.	
				G 610	
				ENCLOSURE ASSEM	
				EXPL., BEFORE BRAZE	
				CAGE CODE	REV
				02887	A
				DRAWING NO.	
				SCALE	
				WEIGHT	
				SHEET	
				OF	




NOTES:
ALL BRAZES MUST BE VACUUM TIGHT AFTER SUBSEQUENT STEP BRAZES AT 925 DEG C AND LESS
DAY'S A, B, AND C CONCENTRIC 0.002 TIR
SURFACE S PERPENDICULAR DIA A 0.002 TIR
FLANGE, SURFACE S, FLAT BETWEEN DIA C DD (1.480) AND 1.300 DIA

REVISIONS		DATE	APPROVE
LYR	DESCRIPTION		



REFERENCE ONLY		UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES METRIC (mm) ARE IN PARENTHESES	DATE	C. C. E. INC.	
		TOLERANCES OF FRACTIONS 1/64		G 610	
		TOLERANCES OF DECIMALS		WATER TUBING ASSEM	
		X .001 XX .0005 (.001)		CASE CODE DRAWING NO.	
		1. BREAK EDGES 1/64 MAX		02887	
		2. DO NOT SCALE THIS DRAWING		SCALE	
		3. DIMENSION TO ANSI Y14.5 1982		CONTRACT/JOB NUMBER	
		4. MAX. ALL MACHINED SURFACES		7	
PART NO	NEXT ASSY.	USED IN		REV	
		APPLICATION		A610-007	
				SHEET OF	
				B	

REV	DESCRIPTION	DATE	APPROVED



REFERENCE ONLY		IN ALL DIMENSIONS SPECIFIED ALL DIMENSIONS ARE IN INCHES METRIC (mm) ARE IN PARENTHESES TOLERANCES OF FRACTIONS 31/64 TOLERANCES OF DECIMALS X .001 XX .0005 .0003 1. BREAK EDGES 1/4" MAX 2. DO NOT SCALE THIS DRAWING 3. DIMENSIONS TO ANSI Y14.5 1982 4. MAX. ALL MACHINED SURFACES	DATE	DRAWN	DATE	C. C. E., INC.
PART NOT MEANT ASSY. USED IN APPLICATION				APPD		G 610 ADJACENT ELECT ASSEM BRAZED
						GAGE CODE 07887
						BRANDING NO. A610-008
						SCALE
						WEIGHT
						SHEET OF


REV	DESCRIPTION	DATE	APPROVED

B6-2-013 X2

A610-008

B6-2-014 X2

A610-003




REFERENCE ONLY		UNLESS OTHERWISE SPECIFIED, ALL DIMENSIONS ARE IN INCHES. METRIC DIMENSIONS ARE IN PARENTHESES. TOLERANCES OF FRACTIONS 31/64 TOLERANCES OF DECIMALS TOLERANCES OF DECIMALS	DATE	C. C. E., INC.	
			DRAWN CHECKED BY	G 610 FINAL GAP ASSEMBLY BRAZED	
				GAGE CODE 02887	REV A
				SCALE	SHEET OF
				WEIGHT	
				CONTRACT/JOB NUMBER	

DEMOUNTABLE GAP PARTS AND ASSEMBLIES

REV	DESCRIPTION	DATE	APPROVED

8" CONFLAT FLANGE
G611-022




ROTATE FLANGE TO AVOID
INTERFERENCE BETWEEN
FLANGE NUTS AND COOLING
TUBE CONNECTOR

C. C. E. INC.		DATE	DATE
G 610 ENCLOSURE ASSEMBLY		DATE	DATE
BRAZED		DATE	DATE
CAGE CODE	BRAVING NO.	CONTRACT/JOB NUMBER	REVISION
02887	A611-005	02887	A
SCALE	WEIGHT	SHEET	OF

UNLESS OTHERWISE SPECIFIED
ALL DIMENSIONS ARE IN INCHES
METRIC (mm) ARE IN PARENTHESES
TOLERANCES OF FRACTIONS 31/64
TOLERANCES OF DECIMALS
X .001 XX .0005 XXX .0008
1. BREAK EDGES 1/64 MAX
2. DO NOT SCALE THIS DRAWING
3. DIMENSIONS TO ANGLE 114.5 1982
4. MAX. ALL MACHINED SURFACES

NOTE:
EXHAUST TUBULATION, G610-016, AND
SOLDER RING B6-1-005 NOT SHOWN


REV	DESCRIPTION	DATE	APPROV
1			



NOTE:
EXHAUST TUBULATION, G610-016, AND
SOLDER RING B6-1-005 NOT SHOWN

UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES METRIC (mm) ARE IN PARENTHESES		DATE		C. C. E., INC.	
TOLERANCES OF FRACTIONS 3/16		DRAWN		G 610	
TOLERANCES OF DECIMALS		CHECK		ADJACENT ELECT ASSEM	
.X .001 .XX .0005 .XXX .001		APPD		BRAZED	
1. BREAK EDGES 1/16 MAX		CONTRACT/JOB NUMBER		GAGE CODE	
2. DO NOT SCALE THIS DRAWING		02887		DRAWING NO.	
3. DIMENSIONS TO ANSI Y14.5 1982		SCALE		REV	
4. MAX. ALL MACHINED SURFACES		1		A611-008	
PART NO. NEXT ASSY.		WEIGHT		SHEET	
APPLICATION		7		OF	


REVISIONS		
REV	DESCRIPTION	DATE



REFERENCE ONLY		DATE		C. C. E., INC.	
				G 611	
				TRIGGER INSULATOR ASSEM	
				BRAZED	
				CAGE CODE	
				02887	
				DRAWING NO.	
				A611-009	
				SCALE	
				SHEET	
				OF	

ALL DIMENSIONS ARE IN INCHES ALL DIMENSIONS ARE IN PARENTHESES METRIC (mm) ARE IN PARENTHESES		DRAWN	
TOLERANCES OF FRACTIONS 4/64		CHKD	
TOLERANCES OF DECIMALS		APPD	
X .001 XX .0005 .0007			
1. BREAK EDGES 1/64 MAX			
2. DO NOT SCALE THIS DRAWING			
3. DIMENSION TO ANSI Y14.5 1982			
4. MAX. ALL MACHINED SURFACES			
PART NOT NEXT ASSY.		CONTRACT/JOB NUMBER	
APPLICATION			

REVISIONS		DATE	APP'D
LYR	DESCRIPTION		





NOTES:
DIAS A AND B CONCENTRIC 0.002 TIR

MATERIAL: OFHC COPPER

REFERENCE ONLY		UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES METRIC (mm) ARE IN PARENTHESES		DATE	C. C. E., INC.	
		TOLERANCES OF FRACTIONS 41/64		DRAWN	G 611	
		TOLERANCES OF DECIMALS		CHKD	TRIGGER EXTENDER	
		X 4001 X 41/64 41/64 41/64		APP'D	BRAZED	
		1. BREAK EDGES 1/64 MAX			CAGE CODE DRAWING NO. G611-014	
		2. DO NOT SCALE THIS DRAWING			REV	
		3. DIMENSION TO ANGLE 114.5 1082			02887	
		4. MAX. ALL MACHINED SURFACES			SCALE	
PART NO. NEXT ASSY.		USED IN		CONTRACT/JOB NUMBER	WEIGHT	SHEET OF
APPLICATION						


REVISIONS		DATE	APVD
LYR	DESCRIPTION		



NOTES:
DIA A, AND B CONCENTRIC 0.002 TIR
SURFACE S FLAT AND PERPENDICULAR DIA A 0.002 TIR

UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES METRIC (mm) ARE IN PARENTHESES		DATE	DRAWN	DATE	C. C. E., INC.	
TOLERANCES OF FRACTIONS 24/64			CHKD		G 611	
TOLERANCES OF DECIMALS			APPD		BODY FLANGE, TRIGGER	
X 40:1					GAGE CODE	
X 40:1					02887	
X 40:1					DRAWING NO.	
X 40:1					G611-020	
1. BREAK EDGES 1/64 MAX					SCALE	
2. DO NOT SCALE THIS DRAWING					02887	
3. DIMENSIONS TO ANSI Y14.5 D80					WEIGHT	
4. MAX ALL MACHINED SURFACES					SHEET	
PART NOT NEXT ASSY. USED IN					OF	
APPLICATION						

LTR	REVISIONS	DATE	APPRO



NOTES:
 SURFACE S FLAT AND PERPENDICULAR TO DIA A 0.002 TIR
 SURFACE FINISH 32 MICROINCHES

MATERIAL: 304 STAINLESS STEEL

REFERENCE ONLY	UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES METRIC (mm) ARE IN PARENTHESES	DATE	C. C. E., INC.
	TOLERANCES OF FRACTIONS 31/64	DRAWN	G 611
	TOLERANCES OF DECIMALS	CHKD	WINDOW RETAINER
	.X .001 .XX .0005 .0005	APPD	
	1. BREAK EDGES 1/64 MAX		
	2. DO NOT SCALE THIS DRAWING		
	3. DIMENSION TO ANGLES 114.5 190.2		
	4. MAX. ALL MACHINED SURFACES		
PART NUMBER ASSY. USED IN	APPLICATION	CONTRACT/JOB NUMBER	CAGE CODE DRAWING NO. REV
			02887 6611-023 B
		WEIGHT	SHEET OF

FLOW CHARTS

C. C. E.

CUSTOMER:

TITLE:

BILL NO: FLOW CHART

NSWC

T610 SPARK GAP

A610-005

NAME/DATE:

CUSTOMER PO:

CONTRACT NO: N60921-94-C-A345 JOB #:

31-Jan-95 #REQUIRED:

DESIG.	DWG. NO.	QTY.	DESCRIPTION	CLEANING PROCESS	DEGREASING PROCESS	PLATING PROCESS	TYPE OF BRAZE	FINAL ASSEMBLY NO.
ENCLOSURE ASSEMBLY								
SS1	G610-010	1	OUTER SHELL, STEEL ENCLOSURE	P013		NICKEL		
SS2	G610-017	2	WATER TUBE, ADJACENT	P013		NICKEL		
SR1	B6-1-005	5	SOLDER/BRAZE RING 1/4" I.D.	P006	P008			
FT1	A610-5EX	2	TUBE SOCKET WELD ELBOW		P008			
SS3	G610-016	1	EXHAUST TUBULATION	P013		NICKEL	HYDROGEN FURNACE	A610-005
SR2			S/A SR1	P006	P008			
SW1	B6-2-001	2	SOLDER WASHER, 2 1/4" O.D.	P005	P008		COPPER BRAZE	
SS4	G610-011	1	TRIGGER ASSEMBLY SPACER	P013		NICKEL	1083 deg. C	
SR3	B6-1-001	2	SOLDER/BRAZE RING 2 17/64" I.D.	P006	P008			
SW2	B6-2-002	2	SOLDER WASHER, 1.80" O.D.	P005	P008			
SW3	B6-2-003	2	SOLDER WASHER, 3 25/64" O.D.	P005	P008			
SS5	G610-008	1	BACKING PLATE, ADJ. ELECTRODE	P013		NICKEL		
SR4	B6-1-002	1	SOLDER/BRAZE RING 3 25/64" I.D.	P006	P008			

C. C. E.

CUSTOMER:

TITLE:

BILL NO: FLOW CHART

NSWC

T610 SPARK GAP

A610-008

NAME/DATE:

CUSTOMER PO:

CONTRACT NO: N60921-94-C-A345 JOB #:

31-Jan-95 #REQUIRED:

DESIG.	DWG. NO.	QTY.	DESCRIPTION	CLEANING PROCESS	DEGREASING PROCESS	PLATING PROCESS	TYPE OF BRAZE	FINAL ASSEMBLY NO.
			ADJACENT ELECTRODE ASSEMBLY					
A1	A610-005-	1	ENCLOSURE ASSEMBLY					
A2	A610-006	1	TRIGGER INSULATOR ASSEMBLY					
SW1	B6-2-015	1	SOLDER WASHER, 1 31/64" O.D.	P005	P008		HYDROGEN FURNACE	
SR1	B6-1-006	2	SOLDER/BRAZE RING, 1/8" I.D.	P006	P008		BRAZE	A610-008
T1	G610-013	1	TRIGGER PIN	P012	P008		PALCUSIL 15	
SW2	B6-2-010	1	SOLDER WASHER, 1 7/64" O.D.	P005	P008		900/850 deg. C	
SW3	B6-2-011	1	SOLDER WASHER, 2 21/64" I.D.	P005	P008			
C1	G610-009	1	ADJ. ELECTRODE COOLING CHANNEL	P011				
SW4	B6-2-009	1	SOLDER WASHER, 2 1/8" O.D.	P005	P008			
SW5	B6-2-012	1	SOLDER WASHER, 3 13/32" O.D.	P005	P008			
T2	G610-002	1	ADJACENT MAIN ELECTRODE	P001	P008	P009		PAGE # 2

C. C. E.
CUSTOMER:
TITLE :
FLOW CHART

NSWC
T610 SPARK GAP
A610-007

NAME/DATE:
CUSTOMER PO:
CONTRACT NO: N60921-94-C-A345 JOB #:
31-Jan-95 #REQUIRED:

DESIG.	DWG. NO.	QTY.	DESCRIPTION	CLEANING PROCESS	DEGREASING PROCESS	PLATING PROCESS	TYPE OF BRAZE	FINAL ASSEMBLY NO.
A610-7EX WATER TUBING ASSEMBLY								
SS1	G610-014	1	WATER CONNECTOR	P013		NICKEL		
SS2	G610-017	2	WATER TUBE ASSEMBLY	P013		NICKEL		
SR1	B6-1-005	5	SOLDER/BRAZE RINGS, 1/4" O.D.	P006	P008		HYDROGEN FURNACE BRAZE	A610-007
FT1	A610-7EX	2	TUBE SOCKET WELD UNION		P008		COPPER	
SR2			S/A SR1	P006	P008		1083/1083 deg. C	
SR3	B6-1-004	2	SOLDER/BRAZE RING, 1/2" O.D.	P006	P008			
SS3	G610-016	1	INNER WATER TUBE ASSEMBLY	P013		NICKEL		
SS4	G610-015	1	OUTER WATER TUBE ASSEMBLY	P013		NICKEL		

C. C. E.
CUSTOMER:
TITLE:
FLOW CHART

NSWC
T610 SPARK GAP
A610-001

NAME/DATE:
CUSTOMER PO:
CONTRACT NO: N60921-94-C-A345 JOB #:
31-Jan-95 #REQUIRED:

DESIG.	DWG. NO.	QTY.	DESCRIPTION	CLEANING PROCESS	DEGREASING PROCESS	PLATING PROCESS	TYPE OF BRAZE	FINAL ASSEMBLY NO.
	A610-1EX		CERAMIC INSULATOR ASSEMBLY					
CE1	G610-003	1	MAIN INSULATOR					
N11	G610-041	1	OPP. ELECTRODE SEAL CUP					
N12	G610-042	1	MAIN INSULATOR SEAL FLANGE					

NOTE:
ASSEMBLY TO BE
DONE AT CERAMIC
PROCESS HOUSE
A610-001
PAGE # 4

C. C. E.
CUSTOMER:
TITLE :
FLOW CHART

NSWC
T610 SPARK GAP
A610-003

NAME/DATE:
CUSTOMER PO:
CONTRACT NO: N60921-94-C-A345 JOB #:
31-Jan-95 #REQUIRED:

DESIG.	DWG. NO.	QTY.	DESCRIPTION	CLEANING PROCESS	DEGREASING PROCESS	PLATING PROCESS	TYPE OF BRAZE	FINAL ASSEMBLY NO.
ELECTRICAL INSULATOR ASSEMBLY								
A1	A610-001	1	CERAMIC INSULATOR ASSEMBLY					
SR1	B6-1-003	2	SOLDER/BRAZE RING, 1/2" I.D.	P006	P008			
A2	A610-007	1	WATER TUBING ASSEMBLY					
SW1	B6-2-008	2	SOLDER WASHER, 4 63/64" O.D.	P005	P008	NICKEL	HYDROGEN FURNACE	
SS1	G610-012	1	END PLATE	P013				
SW2	B6-2-004	1	SOLDER WASHER, 1 11/32" O.D.	P005	P008	NICKEL	BRAZE	A610-003
SS2	G610-005	1	OPP. ELECTRODE SPACER	P013				
SW3	B6-2-005	1	SOLDER WASHER, 1/ 11/32" O.D.	P005	P008	NICKEL	PALCUSIL 15	
SS3	G610-006	1	SOLDER WASHER, 1/ 11/32" O.D.	P013				
SW4	B6-2-006	1	OPP. ELECTRODE COOLING BACKING PLA	P005	P008		900/850 deg. C	
C1	G610-007	1	SOLDER WASHER, 2 21/64" O.D.	P011	P011			
SW5	B6-2-007	2	OPP. ELECTRODE COOLING CHANNEL	P005	P008			
T1	G610-001	1	SOLDER WASHER, 2 1/8" O.D.	P001	P008	P009		
			OPPOSITE MAIN ELECTRODE					

C. C. E.
CUSTOMER:
TITLE:
FLOW CHART

NSWC
T610 SPARK GAP
G0610

NAME/DATE:
CUSTOMER PO:
CONTRACT NO: N60921-94-C-A345 JOB #:
31-Jan-95 #REQUIRED:

DESIG.	DWG. NO.	QTY.	DESCRIPTION	CLEANING PROCESS	DEGREASING PROCESS	PLATING PROCESS	TYPE OF BRAZE	FINAL ASSEMBLY NO.
	G0610		FINAL SPARK GAP ASSEMBLY					
A1	A610-003	1	ELECT.- INSULATOR ASSEMBLY				HYDROGEN	
SW1	B6-2-013	2	SOLDER/BRAZE WASHER, 6.00" O.D.	P005	P008		FURNACE BRAZE	
SW2	B6-2-014	2	SOLDER/BRAZE WASHER, 4 31/32" O.D.	P005	P008		CUSIL	A610-010
A2	A610-008	1	ADJ. ELECTRODE ASSEMBLY				780/780 deg. C	
SS1		1	37 deg. 1/4" TUBE FLARE NUT			NOTE:		
SS2		1	1/4" TUBE FLARE NUT SLEEVE			AFTER COOL DOWN, FIT FLARE NUT, FLARE SLEEVE, AND FLARE EXHAUST TUBULATION AS PER PROCESS P002.		

C. C. E.

CUSTOMER:

TITLE:

BILL NO: FLOW CHART

NSWC

G611 SPARK GAP

A611-005

NAME/DATE:

CUSTOMER PO:

CONTRACT NO: N60921-94-C-A345 JOB #:

31-Jan-95

#REQUIRED:

DESIG.	DWG. NO.	QTY.	DESCRIPTION	CLEANING PROCESS	DEGREASING PROCESS	PLATING PROCESS	TYPE OF BRAZE	FINAL ASSEMBLY NO.
	A611-005		ENCLOSURE ASSEMBLY					
SS1	G611-021	1	OUTER SHELL, STEEL ENCLOSURE	P013		NICKEL		
SS2	G610-017	2	WATER TUBE, ADJACENT	P013		NICKEL		
SR1	B6-1-005	5	SOLDER/BRAZE RING 1/4" I.D.	P006	P008			
FT1	A611-005	2	TUBE SOCKET WELD ELBOW		P008			
SS3	G610-016	1	EXHAUST TUBULATION	P013		NICKEL	HYDROGEN	
SR2			S/A SR1	P006	P008		FURNACE	A611-005
SW1	B6-2-001	2	SOLDER WASHER, 2 1/4" O.D.	P005	P008		COPPER BRAZE	
SS4	G611-011	1	TRIGGER ASSEMBLY SPACER	P013		NICKEL	1083 deg. C	
SR3	B6-1-001	2	SOLDER/BRAZE RING 2 17/64" I.D.	P006	P008			
SW2	B6-2-002	2	SOLDER WASHER, 1.80" O.D.	P005	P008			
SW3	B6-2-003	2	SOLDER WASHER, 3 25/64" O.D.	P005	P008			
SS5	G610-008	1	BACKING PLATE, ADJ ELECTRODE	P013		NICKEL		
SR4	B6-1-002	1	SOLDER/BRAZE RING 3 25/64" I.D.	P006	P008			
SS6	G611-020	1	TRIGGER BODY FLANGE					

C. C. E.
CUSTOMER:
TITLE :
BILL NO: FLOW CHART

NSWC
G611 SPARK GAP
A611-008

NAME/DATE:
CUSTOMER PO:
CONTRACT NO: N60921-94-C-A345 JOB #:
31-Jan-95 #REQUIRED:

DESIG.	DWG. NO.	QTY.	DESCRIPTION	CLEANING PROCESS	DEGREASING PROCESS	PLATING PROCESS	TYPE OF BRAZE	FINAL ASSEMBLY NO.
	A611-8EX		ADJACENT ELECTRODE ASSEMBLY					
A1	A611-005	1	ENCLOSURE ASSEMBLY	P005	P008			
A2	A611-009	1	TRIGGER INSULATOR ASSEMBLY	P005	P008			
SW2	B6-2-010	1	SOLDER WASHER, 1 7/64" O.D.	P011			HYDROGEN FURNACE	A611-008
SW3	B6-2-011	1	SOLDER WASHER, 2 21/64" I.D.	P005	P008		BRAZE	
C1	G610-009	1	ADJ. ELECTRODE COOLING CHANNEL	P005	P008		PALCUSIL 15	
SW4	B6-2-009	1	SOLDER WASHER, 2 1/8" O.D.	P005	P008		900/850 deg. C	
SW5	B6-2-012	1	SOLDER WASHER, 3 13/32" O.D.	P001	P008	P009		
T2	G610-002	1	ADJACENT MAIN ELECTRODE					

NOTE: TO BE MANUFACTURED AND ASSEMBLED BY CERAMIC PROCESS HOUSE

C. C. E.
CUSTOMER:
TITLE:
FLOW CHART

NSWC
G611 SPARK GAP
A610-007

NAME/DATE:
CUSTOMER PO:
CONTRACT NO: N60921-94-C-A345 JOB #:
31-Jan-95 #REQUIRED:

DESIG.	DWG. NO.	QTY.	DESCRIPTION	CLEANING PROCESS	DEGREASING PROCESS	PLATING PROCESS	TYPE OF BRAZE	FINAL ASSEMBLY NO.
	A610-7EX		WATER TUBING ASSEMBLY					
SS1	G610-014	1	WATER CONNECTOR	P013		NICKEL		
SS2	G610-017	2	WATER TUBE ASSEMBLY	P013		NICKEL		
SR1	B6-1-005	5	SOLDER/BRAZE RINGS, 1/4" O.D.	P006	P008			
FT1	A610-7EX	2	TUBE SOCKET WELD UNION		P008			
SR2			S/A SR1	P006	P008			
SR3	B6-1-004	2	SOLDER/BRAZE RING, 1/2" O.D.	P006	P008			
SS3	G610-016	1	INNER WATER TUBE ASSEMBLY	P013		NICKEL		
SS4	G610-015	1	OUTER WATER TUBE ASSEMBLY	P013		NICKEL		
							HYDROGEN FURNACE BRAZE COPPER 1083/1083 deg. C	A610-007

C. C. E.

CUSTOMER:

TITLE :

FLOW CHART

NSWC

G611 SPARK GAP

A610-001

NAME/DATE:

CUSTOMER PO:

CONTRACT NO: N60921-94-C-A345 JOB #:

31-Jan-95 #REQUIRED:

DESIG.	DWG. NO.	QTY.	DESCRIPTION	CLEANING PROCESS	DEGREASING PROCESS	PLATING PROCESS	TYPE OF BRAZE	FINAL ASSEMBLY NO.
	A610-1EX		CERAMIC INSULATOR ASSEMBLY					
CE1	G610-003	1	MAIN INSULATOR				NOTE: ASSEMBLY TO BE DONE AT CERAMI PROCESS HOUSE	A610-001
NI1	G610-041	1	OPP. ELECTRODE SEAL CUP					
NI2	G610-042	1	MAIN INSULATOR SEAL FLANGE					

C. C. E.
CUSTOMER:
TITLE:
FLOW CHART

NSWC
G611 SPARK GAP
A611-003

NAME/DATE:
CUSTOMER PO:
CONTRACT NO: N60921-94-C-A345 JOB #:
31-Jan-95 #REQUIRED:

DESIG.	DWG. NO.	QTY.	DESCRIPTION	CLEANING PROCESS	DEGREASING PROCESS	PLATING PROCESS	TYPE OF BRAZE	FINAL ASSEMBLY NO.
	A611-003		ELECTRODE INSULATOR ASSEMBLY					
A1	A610-001	1	CERAMIC INSULATOR ASSEMBLY					
SR1	B6-1-003	2	SOLDER/BRAZE RING, 1/2" I.D.	P006	P008			
A2	A610-007	1	WATER TUBING ASSEMBLY					
SW1	B6-2-008	2	SOLDER WASHER, 4 63/64" O.D.	P005	P008		HYDROGEN FURNACE	
SS1	G611-012	1	DEMOUNTABLE CONFLAT END PLATE					
SW2	B6-2-004	1	SOLDER WASHER, 1 11/32" O.D.	P005	P008		BRAZE	A611-003
SS2	G610-005	1	OPP. ELECTRODE SPACER	P013		NICKEL	PALCUSIL 15	
SW3	B6-2-005	1	SOLDER WASHER, 1/11/32" O.D.	P005	P008		900/850 deg. C	
SS3	G610-006	1	OPP. ELECTRODE COOLING BACKING PLA	P013		NICKEL		
SW4	B6-2-006	1	SOLDER WASHER, 2 21/64" O.D.	P005	P008			
C1	G610-007	1	OPP. ELECTRODE COOLING CHANNEL	P011	P011			
SW5	B6-2-007	2	SOLDER WASHER, 2 1/8" O.D.	P005	P008			
T1	G610-001	1	OPPOSITE MAIN ELECTRODE	P001	P008	P009		

C. C. E.
CUSTOMER:
TITLE:
FLOW CHART

NSWC
G611 SPARK GAP
G0611

NAME/DATE:
CUSTOMER PO:
CONTRACT NO: N60921-94-C-A345 JOB #:
31-Jan-95 #REQUIRED:

DESIG.	DWG. NO.	QTY.	DESCRIPTION	CLEANING PROCESS	DEGREASING PROCESS	PLATING PROCESS	TYPE OF BRAZE	FINAL ASSEMBLY NO.
	G0610		FINAL SPARK GAP ASSEMBLY					
A1	A610-003 -	1	ELECT. - INSULATOR ASSEMBLY				HYDROGEN	
SW1	B6-2-013	2	SOLDER/BRAZE WASHER, 6.00" O.D.	P005	P008		FURNACE BRAZE	
SW2	B6-2-014	2	SOLDER/BRAZE WASHER, 4 31/32" O.D.	P005	P008		CUSIL	G0611
A2	A610-008	1	ADJ. ELECTRODE ASSEMBLY				780/780 deg. C	
SS1	G611-023	1	WINDOW RETAINER	P013		NICKEL		
SS2		1	37 deg. 1/4" TUBE FLARE NUT			NOTE:		
SS3		1	1/4" TUBE FLARE NUT SLEEVE			AFTER COOL DOWN, FIT FLARE NUT, FLARE SLEEVE, AND FLARE EXHAUST TUBULATION AS PER PROCESS P002.		

PROCESS SPECIFICATIONS

CLEANING TUNGSTEN-COPPER ELECTRODES

POO1

The electrodes should be cleaned shortly before assembly and hydrogen furnace brazing. A long delay may produce enough surface oxidation to prevent a solder from flowing properly.

- 1) Using finger cots, scrub the entire electrode surface with clean water and an abrasive cleaner. The abrasive cleaner must be chemically neutral. Rinse occasionally to check the surface. The electrode is clean when it is no longer a dark copper-gray, but a light and shiny copper-silver color.
- 2) Use a cotton to swab and scrub the corners and surfaces of the electrode with wet abrasive where the braze is to take place. This is to insure that the braze surface areas are particularly clean.
- 3) Rinse the electrode thoroughly in water. Swab Nutri-Clean over the braze area and rinse thoroughly again. Thoroughly dry the electrode.
- 4) Degrease the electrode in a vapor degreaser, or rinse thoroughly in trichlorethane.
- 5) Wrap in lint free paper.

NOTE: It may be beneficial to try vapor or sand blasting the electrode to clean it, so as to save time. Try this only with approval.

BAKE-OUT AND OUTGASING OF SPARK GAP ASSEMBLIES P002

Baking the spark gap at a higher temperature while vacuum pumping on the tubulations outgases the inside surfaces very effectively.

- 1) The exhaust tubulation is 1/4 inch 304 stainless steel.
- 2) Place a 37 deg. flared tube nut and sleeve over the exhaust tubulation. Using a flaring tool flare the end of the tubulation. Inspect the flare for cracks or imperfections in the flare.

NOTE: If any of these conditions exist cut off the flare and repeat the flaring step until correct.

- 3) Attach the flared gap tubulation to the 1/4 inch flare fitted vacuum port inside the bake-out oven. Tighten the flare nut to 135 in/lbs minimum to 145 in/lbs maximum torque. This fitting must be tightened correctly because of the fill gas pressures involved.
- 4) Set the valves to the configuration shown in MTD610-1. Turn on the mechanical roughing pump and pump down for a few minutes. Start diffusion pump and close valves as shown in MTD610-2 and allow the system to pump down to a pressure of 150um Hg, which is metered on the thermocouple gauge.
- 5) Brush acetone on each of the tubing connections and braze joints while looking for a jump in the thermocouple meter. Such a sudden apparent increase in pressure indicates a leak at that joint. If a leak exists, shut down the system and repair the bad joint. Restart the system according to step 4. If no leak exists, continue on.
- 6) Place heat shielding above and below the gap manifold to protect the spark gap from direct heat of the oven coils. Monitor the oven temperature with a standard temperature thermocouple weighted down with small scrap ceramic pieces.
- 7) Close the valves to the pressure gauge and fill gas regulator as shown in MTD610-3.
Plug the oven in and turn on. Set the temperature to 520 degrees C for the Tungsten-Copper electrodes.
The oven will begin to warm up and must be watched closely after about 25 minutes.
- 8) When the desired temperature has been reached allow the gap to bake while being pumped for one hour, checking the temperature every 10-15 minutes. The temperature should remain within plus/minus 20 degrees C of the desired temperature.
- 9) While still maintaining a constant temperature as above, close the manifold valve going to the diffusion pump and open the air valve as per drawing MTD610-4. This allows air inside the gap and the electrode surfaces to oxidize at high temperature. Every 5 minutes the air valve should be closed, and the system re-evacuated in the 2 step procedure shown in MTD610-5 and MTD610-6. Then fresh

air re-introduced as per drawing MTD610-4 in order to maintain a constant supply of oxygen and water vapor to the electrode surfaces. After 30 minutes of this process oxidize and close off the air valve. Turn off and unplug the oven. Spark gaps with molybdenum electrodes or parts must not be left at low pressure during cooling (after oxidation) as the molybdenum oxide has a high vapor pressure in vacuum.

10) At temperatures below 300 degrees C the oven door may be opened slightly to expedite cooling.

The gap must be cooled to within 5 degrees C of room temperature before continuing.

NOTE:

- a) The gap must be supported with plastic or ceramic.
 - b) Phenolic should be used to insulate the oven rack and heater coils from spurious arcs/corona. Electrical tape may be used for securing the phenolic.
- 1) Install a 10k-100k ohm 2W resistor from the trigger to the adjacent electrode. This prevents arcing from the trigger electrode from occurring.
 - 2) Assemble the circuit shown in MDT610-15. If a voltage greater than 100kV is to be used, a plexiglass cover should be installed and the high voltage leads inserted through the center and bottom holes. Purge the oven volume with freon 12, which is available through refrigeration and plumbing supply distributors. Be sure all high voltage leads are supported properly and all grounds are connected. Make sure oven is unplugged.
 - 3) Evacuate the spark gap manifold as per drawings MDT610-5 and MDT610-6, and purge twice with the fill gas mixture.
 - 4) Close off all valves to the vacuum pumps and vacuum gauge. Fill the spark gap with the hydrogen gas to the projected fill pressure using the procedure and valve configuration found on drawings MDT610-7 and MDT610-8.
 - 5) Turn the high voltage on and increase the potential. Using the steps shown on drawing MDT610-9 continue on. If no breakdown occurs at a "reasonably low" voltage, decrease the pressure. If static breakdown occurs at too low of a voltage, increase the pressure. It is often helpful to age the gap about 20 shots at about 15% higher SBV than desired and then adjust to the necessary lower SBV.
 - 6) When the gap fires reliably at the desired SBV, about 10 times, the gap may be removed from the manifold. Turn off the high voltage power supply and ground the charging capacitor. Leave the grounding stick hooked to the on the capacitor. At this point refer to drawing MTD610-10 for valve configuration and instructions. Remove all voltage connections to the gap and polish the end of the tubulation with steel wool. Leave a long tubulation in case repumping is necessary. Oil the tubulation and pinch-off tool rollers with castor oil. While supporting the gap, pinch the tubulation in the polished area with a smooth and powerful squeeze of the pinch-off tool. The gap should be loose without pulling or twisting it. Label the gap with a paper tag to identify it's SBV.

ELECTRICAL TESTING OF THE SPARK GAP

P004

NOTE: Refer to Table 1 for calibration of the trigger unit.

- 1) Assemble the circuit as shown in drawing MTD610-16.
- 2) With the trigger unit off, check to be sure the SBV is correct. (if possible)
- 3) Measure the minimum electrode to electrode breakdown voltage (e-e min). Turn the trigger unit on and adjust the voltage to 100kV. Turn on the main power supply and slowly increase the voltage across the spark gap. While occasionally triggering, find the voltage for which the gap will trigger and conduct. Record the voltage at and above the point at which the gap will always conduct. Below this voltage the gap should fire only intermittently. This voltage is the e-e min voltage.
- 4) Measure the minimum trigger voltage necessary to cause a breakdown across the gap, (t min). At e-e min trigger the gap at consecutively lower trigger voltages. When the gap will no longer fire when triggered, increase the trigger voltage till it does. If the gap fires reliably (about 10 times) at this voltage and will not fire at any lower trigger voltage, record the trigger voltage as the minimum trigger voltage, (t min).
- 5) Record any odd behavior.

MAKING SOLDER/BRAZE WASHERS

P005

Most solder washers to date have been made by hand. Much care must be taken in order to insure the washers do not suffer from being handled to heavily and deforming them to the point of being useless.

- 1) Adjust the knife edge slide rule compass to the desired radius corresponding to the washer's outside diameter. Care must be taken at this point, double check the scale on the slide rule compass with another scale, as the scale on the slide rule compass might read over slightly.
- 2) With the solder stock on heavy cardboard on a table, center the compass on the solder and scribe a cutting line heavily into the solder stock. Scribe all the outside diameters of all the solder washers of this size that are needed.
- 3) Cut the washers out carefully with a small pair of scissors. The more accurately they are cut out, the more likely they will fit the work without modification.
- 4) Readjust the compass for the radius corresponding to the inside diameter of the washer. Use the same center hole of the solder disk and scribe a cutting line for the inside diameter. Scribe all disks which use this size at the same time.
- 5) Cut along the inside line with an "Exacto" knife enough to get the tips of the small scissors in, then carefully cut the rest of the way with the scissors.
- 6) Flatten each solder washer by rubbing it down on a hard surface with the back of a pair of tweezers. Check each solder washer to be sure it fits the work it is intended for. They must fit without bending or buckling, and must not be very loose. Vapor degrease them.

NOTES:

- a) BT/CUSIL solder is soft and will bend very easily.
- b) Palcusil solder, or its equivalent, is very hard and is difficult to flatten out. Care must be taken not to bend it sharply.
- c) Subassemblies use Palcusil solder. Final assemblies use BT/CUSIL solder.
- d) Save and identify all scrap solder.

SOLDER RINGS

P006

Solder rings to date have been made by hand. It requires a minimum of tools but a maximum of patience. So far only Palcusil 25 has been made into rings.

For small rings which go onto the exhaust tubulation:

- 1) Use a dowel slightly smaller than 0.25 inches, such as a drill bit or a small screwdriver shank and wrap the wire tightly onto it.
- 2) The coil should spring back some. Try to fit it onto a tubulation. If it fits cut rings into groups of three (3). If they are too small cut them off and stretch them one by one. There should not be any gaps in the ring when it fits onto the tubulation. If the rings are too big, under cut them one by one and squeeze them down to the right diameter. The rings must fit snugly against the tubulation and not have any gaps between the ends of the rings.

For larger that fit next to the tubulation disc and flange:

- 1) Use a dowel as above but find one that is about 0.6-0.7 inches in diameter. Wrap the wire tightly onto it. When the coil is removed it will spring back to a larger but variable diameter.
- 2) Cut off enough of the coil to make a ring to fit. Carefully work with the ring to increase or decrease its diameter to fit into the flange hole. It must fit squarely with a small amount of spring (but not too much), be very flat, and have no gap where the ends meet (although they may overlap slightly).
- 3) Degrease the finished solder rings.

LEAK CHECKING

P007

Leak checking has been done on a Veeco brand helium leak detector with a variety of fixtures. A plate about 12 inches square with a silicon rubber sheet on top and a 1/4 inch copper tube on the bottom has been most useful in leak checking. Use silicon vacuum grease sparingly on rubber seals to form a good seal.

- 1) If there is an obvious defect in the assembly which will cause a vacuum leak re-braze the defect before continuing the leak check.
- 2) Place the flange upside down on the fixture. Plug the electrode hole (if applicable) with a rubber stopper. Evacuate the assembly and proceed checking for leaks according to the leak detector's specific directions.
- 3) If problems with seals are encountered and leak checking cannot be done reliably, brushing acetone around edges, cracks and other suspect areas will plug the leak long enough to leak check the brazes on the rest of the flange. Care must be taken not to get acetone in areas where a check is wanted, as a false reading will be given.
- 4) When a definite result is obtained remove the flange from the fixture and:
 - a) For opposite flanges, turn it upside down to check for leaks in the opposite direction.
 - b) For adjacent flanges, continue on.
- 5) Clean the flange with acetone and then vapor degrease. No silicon grease may remain on the flange. Wrap the flange in lint free paper and store until needed. Label the flange with a paper tag if it is not easily identified.

VAPOR DEGREASING

P008

- 1) The part to be degreased should not be too dirty. Remove any obvious dirt, dust or grease with a paper towel and solvent. Doing this helps insure a thorough cleaning of the parts over a long period of time.
- 2) Hang the parts on a hook, or place them in a basket. Place the parts in the degreaser for about 5 minutes. If there are a lot of parts in the degreaser at the same time, allow them to remain there for about 10 minutes or longer to be sure of a good cleaning.
- 3) Remove the parts and dry them under forced air. Wrap them in lint free paper and store until needed.

CHEMICAL ETCHING OF TUNGSTEN-COPPER ELECTRODES P009

The surface of tungsten-copper electrodes have sometimes been acid etched to remove the surface copper and hence reduce wall sputtering. The etching is done on the flange assembly to facilitate holding.

- 1) Make an acid bath of:

25ml Hydrofloric Acid
125ml Nitric Acid
480ml Distilled Water

- 2) Don appropriate safety equipment (i.e. gloves, face shield and apron). Carefully swab with cotton swabs, or a cotton ball and a small wire brush the acid mixture over the surface of the electrode. Do not swab the braze area. Acid mixture must not run onto braze areas or the flange.

- 3) Continue swabbing the surface for about 30 minutes or until the electrode no longer has a copper color to it.

- 4) Rinse the flange assembly in hot water, then in acetone and dry under forced air. Wrap the flange assembly in lint free paper until it is needed.

NOTE: Try, with approval only, a stronger acid mixture

50ml Hydrofloric Acid
250ml Nitric Acid
500ml Distilled Water

TUBULATION CAP OF THE SPARK GAP

P010

After pinching the spark gap off and performing the electrical testing, the tubulation must have a small copper cap soldered onto the end so as to protect the seal against breaking. The tools needed are as follows:

- Propane torch and igniter
- Fire brick
- Needle nose pliers
- Good quality rosin core solder
- Triclorethane

1) Large spark gaps may have long tubulations, small spark gaps must have tubulations as short as possible.

2) Clean the end of the tubulation with the triclorethane. The tubulation on large spark gaps should be straightened out for now.

NOTE: DANGER! Because of the flammable nature of triclorethane it must be put away before proceeding with the next step.

3) Heat up the fire brick with the torch. Place the copper cap on the hot portion of the fire brick. Melt solder inside the cap, heating with torch as necessary. Do not over heat the copper cap as it is very thin and will oxidize away very easily.

4) Dip the end of the tubulation into the cap and molted solder. Make sure the cap is on straight with respect to the tubulation. Allow the solder to solidify before moving the tubulation.

5) Scrape off the worst of the solder flux. Check the neatness of the soldering and cap alignment. On large spark gaps curl the tubulation under the surface of the flange.

NOTE:

If the rosin core solder will not flow, clean the parts and use some stainless steel solder flux.

COPPER CLEANING

P011

1) Copper is cleaned using BCB COPPER CLEANER. Clean the copper parts according to the cleaner's packaged instructions. This cleaner is available through:

Hubbard-Hall, Inc.
563 S. Leonard St.
Waterbury, Ct 06725
Phone (203) 756-5521

MOLYBDENUM AND TUNGSTEN CLEANING PROCESS

P012

Molybdenum and tungsten use the same cleaning process.

- 1) Vapor degrease the parts as per instruction P008.
- 2) Very dirty oxidized parts must be vapor blasted and degreased.
- 3) Mix a 33% Potassium Hydroxide (KOH) and distilled water solution.
- 4) Connect a positive 6 volt power supply to the molybdenum parts and submerge them in the KOH solution. Molybdenum parts are the positive electrode, and a carbon electrode is the negative electrode. Turn the power supply on until the parts are a bright silver-gray.

NOTE:

- a) Other negative electrode materials might be used with approval.
 - b) Only small amounts of current are necessary. Use a current limiting resistor when appropriate.
- 5) Rinse and dry the parts in the following sequence:
 - Cold water
 - Hot water
 - Acetone
 - Dry under hot forced air
 - 6) Wrap the parts in lint free paper and store until needed.

CLEANING OF STAINLESS STEEL PARTS

PO13

All stainless steel parts should be cleaned shortly before assembly. This will prevent any dust, oils, or other substances from contaminating any surfaces that are weld, or braze joints.

- 1) Inspect parts to be cleaned. Check parts for any material left from the milling process (ie.. filings or shavings). Using a lint free cloth wipe off any particles before proceeding.
- 2) Prepare a hot alkali degreasing solution as follows:
 - a) Use DIVERSEY WYANDOTTE MAXAMP cleaner.
 - b) Dissolve 8 ounces/gallon of cleaner into deionized water heated to 50 degrees C.
 - c) Heat solution to between 70-80 degrees C.
 - d) Clean anodically at 80-100 amps/square foot for 30-90 seconds.
- 3) Rinse for 1 minute in deionized water.
- 4) Rinse in methanol.
- 5) Dry in hot oven.
- 6) Dip parts in a 50% by volume solution of hydrochloric acid for approximately 5 minutes.
- 7) Rinse in deionized water.
- 8) Dry in hot oven.
- 9) Wrap in lint free paper, package carefully, and send to proccesser for nickel plating.







NOTE:


This proccess does not apply to any conflats flanges, as it could destroy the knife edge on the flange.

SYSTEM START-UP, AND ROUGH OUT

NOTES:

1	START MECHANICAL ROUGHING PUMP
---	--------------------------------

SYMBOLS	
	THERMOCOUPLE GAUGE
	IONIZATION GAUGE
	OPEN VALVE
	VACUUM GAUGE
	PRESSURE GAUGE
	CLOSED VALVE


[illegible]

REV	DESCRIPTION	DATE	APP'D
1			

OXIDIZING SEQUENCE NOTES:

1	CLOSE OFF VALVES TO THE DIFFUSION PUMP
2	OPEN VALVE TO AIR

SYMBOLS	
TCG	THERMOCOUPLE GAUGE
IG	IONIZATION GAUGE
○	OPEN VALVE
⊗	CLOSED VALVE
⊙	VACUUM GAUGE
⊙	PRESSURE GAUGE



REFERENCE ONLY		UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES METRIC GAPS ARE IN PARENTHESES TOLERANCES OF FRACTIONS 21/64 TOLERANCES OF DECIMALS IN 0.01 IN 0.005 IN 0.002	DATE 12-94	C. C. E.	
		1. WEIGHT 1/44 MAX 2. DIMENSIONS 1/44 MAX 3. DIMENSIONS TO ANGLES 1/45 1/88 4. MAX ALL MACHINED SURFACES	TRAVN B.V.M. 12-94	GAP PRESSURIZING SEQUENCE	
		CONTRACT/JOB NUMBER NG0921-94-C-4345	DRWING NO. 02887	REV A	
		SCALE N/A	VECBIT	SHEET 4 OF 14	

REFERENCE ONLY	UNLESS OTHERWISE NOTED, DIMENSIONS ARE IN INCHES METRIC (mm) ARE IN PARENTHESES	DRAWN BY: M. J. 12-94	DATE	C. C. E.	
	TOLERANCES OF FINISHES: ±0.04	CHKD		GAP PRESSURIZING SEQUENCE	
	TOLERANCES OF DIMENSIONS	APPD			
	IN SOLID IN SOLID CHSLT				
	1. BREAK ENDS 1/64 MAX				
	2. DO NOT SCALE THIS DRAWING				
	3. DIMENSIONS TO FACE UNLESS NOTED OTHERWISE				
	4. HIDE ALL UNFINISHED SURFACES				
PART NO: 1001-1001	UNLESS DIM		SIZE: CAGED 020887	DRAWING NO: MDT610-5	REV: A
APPLICATION			SCALE: N/A	VELOCITY	SHEET: 5 OF 14



REV	DESCRIPTION	DATE	APPROV

RE-EVACUATING SYSTEM STEP 2

NOTES:

1	CLOSE BLEEDER VALVE
2	OPEN MAIN LINE VALVE TO THE DIFFUSION PUMP.
3	PUMP SYSTEM BACK DOWN TO 150um Hg.

SYMBOLS	
TCG	THERMOCOUPLE GAUGE
TG	IONIZATION GAUGE
○	OPEN VALVE
⊗	CLOSED VALVE
⊙	VACUUM GAUGE
⊕	PRESSURE GAUGE



REFERENCE ONLY		UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES METRIC DIMS ARE IN PARENTHESES		DRAWN B.V.M. 12-94	DATE	C. C. E.	
		TOLERANCES OF FRACTIONS 1/64		CHK		GAP PRESSURIZING SEQUENCE	
		TOLERANCES OF DECIMALS		APPJ			
		1. .0005					
		2. .001					
		3. .002					
		4. .005					
		5. .01					
		6. .02					
		7. .05					
		8. .1					
		9. .2					
		10. .5					
		11. 1					
		12. 2					
		13. 5					
		14. 10					
		15. 20					
		16. 50					
		17. 100					
		18. 200					
		19. 500					
		20. 1000					
		21. 2000					
		22. 5000					
		23. 10000					
		24. 20000					
		25. 50000					
		26. 100000					
		27. 200000					
		28. 500000					
		29. 1000000					
		30. 2000000					
		31. 5000000					
		32. 10000000					
		33. 20000000					
		34. 50000000					
		35. 100000000					
		36. 200000000					
		37. 500000000					
		38. 1000000000					
		39. 2000000000					
		40. 5000000000					
		41. 10000000000					
		42. 20000000000					
		43. 50000000000					
		44. 100000000000					
		45. 200000000000					
		46. 500000000000					
		47. 1000000000000					
		48. 2000000000000					
		49. 5000000000000					
		50. 10000000000000					
		51. 20000000000000					
		52. 50000000000000					
		53. 100000000000000					
		54. 200000000000000					
		55. 500000000000000					
		56. 1000000000000000					
		57. 2000000000000000					
		58. 5000000000000000					
		59. 10000000000000000					
		60. 20000000000000000					
		61. 50000000000000000					
		62. 100000000000000000					
		63. 200000000000000000					
		64. 500000000000000000					
		65. 1000000000000000000					
		66. 2000000000000000000					
		67. 5000000000000000000					
		68. 10000000000000000000					
		69. 20000000000000000000					
		70. 50000000000000000000					
		71. 100000000000000000000					
		72. 200000000000000000000					
		73. 500000000000000000000					
		74. 1000000000000000000000					
		75. 2000000000000000000000					
		76. 5000000000000000000000					
		77. 10000000000000000000000					
		78. 20000000000000000000000					
		79. 50000000000000000000000					
		80. 100000000000000000000000					
		81. 200000000000000000000000					
		82. 500000000000000000000000					
		83. 1000000000000000000000000					
		84. 2000000000000000000000000					
		85. 5000000000000000000000000					
		86. 10000000000000000000000000					
		87. 20000000000000000000000000					
		88. 50000000000000000000000000					
		89. 100000000000000000000000000					
		90. 200000000000000000000000000					
		91. 500000000000000000000000000					
		92. 1000000000000000000000000000					
		93. 2000000000000000000000000000					
		94. 5000000000000000000000000000					
		95. 10000000000000000000000000000					
		96. 20000000000000000000000000000					
		97. 50000000000000000000000000000					
		98. 100000000000000000000000000000					
		99. 200000000000000000000000000000					
		100. 500000000000000000000000000000					
		101. 1000000000000000000000000000000					
		102. 2000000000000000000000000000000					
		103. 5000000000000000000000000000000					
		104. 10000000000000000000000000000000					
		105. 20000000000000000000000000000000					
		106. 50000000000000000000000000000000					
		107. 100000000000000000000000000000000					
		108. 200000000000000000000000000000000					
		109. 500000000000000000000000000000000					
		110. 1000000000000000000000000000000000					
		111. 2000000000000000000000000000000000					
		112. 5000000000000000000000000000000000					
		113. 10000000000000000000000000000000000					
		114. 20000000000000000000000000000000000					
		115. 50000000000000000000000000000000000					
		116. 100000000000000000000000000000000000					
		117. 200000000000000000000000000000000000					
		118. 500000000000000000000000000000000000					
		119. 1000000000000000000000000000000000000					
		120. 2000000000000000000000000000000000000					
		121. 5000000000000000000000000000000000000					
		122. 10000000000000000000000000000000000000					
		123. 20000000000000000000000000000000000000					
		124. 50000000000000000000000000000000000000					
		125. 100000000000000000000000000000000000000					
		126. 200000000000000000000000000000000000000					
		127. 500000000000000000000000000000000000000					
		128. 1000000000000000000000000000000000000000					
		129. 2000000000000000000000000000000000000000					
		130. 5000000000000000000000000000000000000000					
		131. 100					
		132. 200					
		133. 500					
		134. 1000					
		135. 2000					
		136. 5000					
		137. 100					
		138. 200					
		139. 500					
		140. 1000					
		141. 2000					
		142. 5000					
		143. 100					
		144. 200					
		145. 500					
		146. 1000					
		147. 2000					
		148. 5000					
		149. 100					
		150. 200					
		151. 500					
		152. 1000					
		153. 2000					
		154. 5000					
		155. 100					
		156. 200					
		157. 500					
		158. 1000					
		159. 2000					
		160. 5000					
		161. 100					
		162. 200					
		163. 500					
		164. 1000					
		165. 2000					
		166. 5000					
		167. 100					
		168. 200					
		169. 500					
		170. 1000					
		171. 2000					
		172. 5000					
		173. 100					
		174. 200					
		175. 500					
		176. 1000					
		177. 2000					
		178. 5000					
		179. 100					
		180. 200					
		181. 500					
		182. 1000					


REV	DESCRIPTION	DATE	APPROV

SPARK GAP FILL STEP 1

NOTES:


1	CLOSE ALL VALVES TO VACUUM PUMPS.
2	CLOSE VALVE TO SPARK GAP MANIFOLD.
3	CLOSE VALVE TO VACUUM GAUGE
4	OPEN VALVES TO PRESSURE GAUGE AND FILL GAS REGULATOR.
5	ADJUST REGULATOR TO THE APPROPRIATE PRESSURE.

SYMBOLS	
TCG	THERMOCOUPLE GAUGE
TG	IONIZATION GAUGE
○	OPEN VALVE
⊗	CLOSED VALVE
⊙	VACUUM GAUGE
⊕	PRESSURE GAUGE



BAKE-OUT OVEN

-15 to 0 PSI



REFERENCE ONLY		UNLESS OTHERWISE SPECIFIED, ALL DIMENSIONS ARE IN INCHES. METRIC DIMS ARE IN PARENTHESES.	DATE	12-94
		TOLERANCES OF FRACTIONS 3/16"	DESIGN	BRWN B.V.V.
		TOLERANCES OF DECIMALS	APPD	
		IN 1/16"		
		IN 1/32"		
		IN 1/64"		
		IN 1/128"		
		IN 1/256"		
		IN 1/512"		
		IN 1/1024"		
		IN 1/2048"		
		IN 1/4096"		
		IN 1/8192"		
		IN 1/16384"		
		IN 1/32768"		
		IN 1/65536"		
		IN 1/131072"		
		IN 1/262144"		
		IN 1/524288"		
		IN 1/1048576"		
		IN 1/2097152"		
		IN 1/4194304"		
		IN 1/8388608"		
		IN 1/16777216"		
		IN 1/33554432"		
		IN 1/67108864"		
		IN 1/134217728"		
		IN 1/268435456"		
		IN 1/536870912"		
		IN 1/1073741824"		
		IN 1/2147483648"		
		IN 1/4294967296"		
		IN 1/8589934592"		
		IN 1/17179869184"		
		IN 1/34359738368"		
		IN 1/68719476736"		
		IN 1/137438953472"		
		IN 1/274877906944"		
		IN 1/549755813888"		
		IN 1/1099511627776"		
		IN 1/2199023255552"		
		IN 1/4398046511104"		
		IN 1/8796093022208"		
		IN 1/17592186444416"		
		IN 1/35184372888832"		
		IN 1/70368745777664"		
		IN 1/14073749155328"		
		IN 1/28147498310656"		
		IN 1/56294996621312"		
		IN 1/112589993242624"		
		IN 1/225179986485248"		
		IN 1/450359972970496"		
		IN 1/900719945940992"		
		IN 1/1801439891881984"		
		IN 1/3602879783763968"		
		IN 1/7205759567527936"		
		IN 1/14411519135055872"		
		IN 1/28823038270111744"		
		IN 1/57646076540223488"		
		IN 1/115292153080446976"		
		IN 1/230584306160893952"		
		IN 1/461168612321787904"		
		IN 1/922337224643575808"		
		IN 1/1844674449287151616"		
		IN 1/3689348898574303232"		
		IN 1/7378697797148606464"		
		IN 1/14757395594297212928"		
		IN 1/29514791188594425856"		
		IN 1/59029582377188851712"		
		IN 1/118059164754377703424"		
		IN 1/236118329508755406848"		
		IN 1/472236659017510813696"		
		IN 1/944473318035021627392"		
		IN 1/1888946636070043254784"		
		IN 1/3777893272140086509568"		
		IN 1/7555786544280173019136"		
		IN 1/15111573088560346038272"		
		IN 1/30223146177120692076544"		
		IN 1/60446292354241384153088"		
		IN 1/120892584708482768306176"		
		IN 1/241785169416965536612352"		
		IN 1/483570338833931073224704"		
		IN 1/967140677667862146449408"		
		IN 1/1934281355335724292898816"		
		IN 1/3868562710671448585797632"		
		IN 1/7737125421342897171595264"		
		IN 1/15474250842685794343190528"		
		IN 1/30948501685371588686381056"		
		IN 1/61897003370743177372762112"		
		IN 1/123794006741486354745524224"		
		IN 1/247588013482972709491048448"		
		IN 1/495176026965945418982096896"		
		IN 1/990352053931890837964193792"		
		IN 1/1980704107863781675928387584"		
		IN 1/3961408215727563351856775168"		
		IN 1/7922816431455126703713550336"		
		IN 1/15845632862910253407427100672"		
		IN 1/31691265725820506814854201344"		
		IN 1/63382531451641013629708402688"		
		IN 1/126765062903282027259416805376"		
		IN 1/253530125806564054518833610752"		
		IN 1/507060251613128109037667221504"		
		IN 1/1014120503226256218075334443008"		
		IN 1/2028241006452512436150668886016"		
		IN 1/4056482012905024872301337772032"		
		IN 1/8112964025810049744602675544064"		
		IN 1/16225928051620099489205351088128"		
		IN 1/32451856103240198978410702176256"		
		IN 1/64903712206480397956821404352512"		
		IN 1/129807424412960795913642808705024"		
		IN 1/259614848825921591827285617410048"		
		IN 1/519229697651843183654571234820096"		
		IN 1/1038459395303686367309142469640192"		
		IN 1/2076918790607372734618284939280384"		
		IN 1/4153837581214745469236569878560768"		
		IN 1/8307675162429490938473139757121536"		
		IN 1/16615350324858981876946279514243072"		
		IN 1/33230700649717963753892559028486144"		
		IN 1/66461401299435927507785118056972288"		
		IN 1/132922802598871855015570236113944576"		
		IN 1/265845605197743710031140472227889152"		
		IN 1/531691210395487420062280944455778304"		
		IN 1/1063382420790974840124561888911556608"		
		IN 1/2126764841581949680249123777823113216"		
		IN 1/4253529683163899360498247555646226432"		
		IN 1/8507059366327798720996495111292452864"		
		IN 1/17014118732655597441992990222584905728"		
		IN 1/34028237465311194883985980445169811456"		
		IN 1/68056474930622389767971960890339622912"		
		IN 1/136112949861244779535943921780679245824"		
		IN 1/272225899722489559071887843561358491648"		
		IN 1/544451799444979118143775687122716983296"		
		IN 1/1088903598889958236287551374245433965504"		
		IN 1/2177807197779916472575102748490867931008"		
		IN 1/4355614395559832945150205496981735862016"		
		IN 1/8711228791119665890300410993963471724032"		
		IN 1/17422457822239317780600821987926943448064"		
		IN 1/34844915644478635561201643975853886896128"		
		IN 1/69689831288957271122403287951707773792256"		
		IN 1/139379662577914542244806575903415547584512"		
		IN 1/278759325155829084489613151806831095168024"		
		IN 1/557518650311658168979226303613662190336048"		
		IN 1/1115037300623316337958452607227324380672096"		
		IN 1/2230074601246632675916905214454648761344192"		
		IN 1/4460149202493265351833810428909297522688384"		
		IN 1/8920298404986530703667620857818595045376768"		
		IN 1/17840596809973061407335241715637190090753536"		
		IN 1/35681193619946122814670483431274380181507072"		
		IN 1/71362387239892245629340966862548760363014144"		
		IN 1/142724774479784491258681933725097520726028288"		
		IN 1/285449548959568982517363867450195041452056576"		
		IN 1/570899097919137965034727734900390082904113152"		
		IN 1/1141798195838275930069455469800780165808226304"		
		IN 1/2283596391676551860138910939601560331616452608"		
		IN 1/4567192783353103720277821879203120663232905216"		
		IN 1/9134385566706207440555643758406241326465810432"		
		IN 1/18268771133412414881111287516812482652931620864"		
		IN 1/36537542266		


REVISIONS		DATE	APPROVED
LYN	DESCRIPTION		

SPARK GAP FILL STEP 2

NOTES:


1	CLOSE VALVE TO FILL GAS REGULATOR.
2	OPEN VALVE TO THE SPARK GAP MANIFOLD.
3	CHECK READING ON PRESSURE GAUGE.

SYMBOLS	
TCG	THERMOCOUPLE GAUGE
IG	IONIZATION GAUGE
○	OPEN VALVE
⊗	CLOSED VALVE
⊙	VACUUM GAUGE
⊕	PRESSURE GAUGE



BAKE-OUT OVEN

-15 to 0 PSI



REFERENCE ONLY		UNLESS OTHERWISE SPECIFIED, ALL DIMENSIONS ARE IN INCHES. METRIC DIMENSIONS ARE IN PARENTHESES.	DATE	C. C. E.	
		TOLERANCES OF FRACTIONS 3/16"	DRAWN B.M.M.	GAP PRESSURIZING SEQUENCE	
		TOLERANCES OF DECIMALS	CHKD		
		1. BEAM EDGES 1/64 MAX	APPD		
		2. DO NOT SCALE THIS DRAWING			
		3. DIMENSIONS TO ANSI Y14.5 1982			
		4. HIDE ALL MACHINED SURFACES			
PART NO.	NEW APPR.	USED IN	CONTRACT/ORD. NUMBER	SIZE/CAGE CODE	REV
			NE0921-94-C-A345	02087	A
APPLICATION			SCALE	N/A	SHEET 8 OF 14

UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES METRIC (mm) ARE IN PARENTHESES TOLERANCES OF FRACTIONS 1/64 APPLY TOLERANCES IF DECIMALS	DATE 12-94	C. C. E.	
1. BREAK EDGES 1/64 MAX 2. DO NOT SCALE THIS DRAWING 3. DIMENSIONS MUST MATCH 4. HIDE ALL UNWANTED MARKS	DRAWN B.M.V. CHOR APPD	GAP PRESSURIZING SEQUENCE	
SIZE 11x17 DATE 02/87 SCALE N/A	DRAWING NO. MDT610-9	REV A	SHEET 9 OF 14
CONTRACT/JOB NUMBER N6092L-94-C-A345			


REV	DESCRIPTION	DATE	APPROV
1			

SPARK GAP TUBULATION PINCH-OFF

NOTES:


1	CLOSE OFF VALVE TO THE FILL GAS REGULATOR.
2	CLOSE OFF VALVE TO THE SPARK GAP MANIFOLD.
3	PINCH OFF TUBULATION AS INSTRUCTED IN THE MANUAL.

SYMBOLS	
TCG	THERMOCOUPLE GAUGE
IG	IONIZATION GAUGE
○	OPEN VALVE
⊗	CLOSED VALVE
⊙	VACUUM GAUGE
⊕	PRESSURE GAUGE



BAKE-OUT OVEN

-15 to 0 PSI



REFERENCE ONLY		UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES METRIC (mm) ARE IN PARENTHESES TOLERANCES OF DECIMALS	DATE	C. C. E.	
		X .001	12-94	GAP PRESSURIZING SEQUENCE	
		1. BORE EDGES 1/64 MAX			
		2. DO NOT SCALE THIS DRAWING			
		3. DIMENSIONS ARE TO FACE UNLESS			
		4. FINISH ALL MACHINED SURFACES			
PART NO.	NEST ASST.	UNLESS	CONTRACT/JOB NUMBER	SCALE	WEIGHT
		7	NG0921-94-C-A345	N/A	
			DRAWN BY	REV	SHEET 10 OF 14
			APPJ	02007	

REV	DESCRIPTION	DATE	APPROV


SYSTEM VENT

NOTES:

1	VALVES ON REGULATOR AND FILL GAS TANK MUST BE CLOSED OFF.
2	OPEN SYSTEM VALVE TO REGULATOR.
3	OPEN VALVE TO GAP MANIFOLD.
4	OPEN VENT VALVE.

SYMBOLS	
TCG	THERMOCOUPLE GAUGE
IG	IONIZATION GAUGE
○	OPEN VALVE
⊗	CLOSED VALVE










BAKE-OUT OVEN




REFERENCE ONLY		UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES METRIC DIMS ARE IN PARENTHESES	DRAWN B.V.M. 12-94	DATE	C. C. E.
		TOLERANCES OF FRACTIONS 1/64			GAP PRESSURIZING SEQUENCE
		TOLERANCES OF DECIMALS			
		1. 30.01 2. 30.01 3. 30.01 4. 30.01			
		5. 30.01 6. 30.01 7. 30.01 8. 30.01			
		9. 30.01 10. 30.01 11. 30.01 12. 30.01			
		13. 30.01 14. 30.01 15. 30.01 16. 30.01			
		17. 30.01 18. 30.01 19. 30.01 20. 30.01			
		21. 30.01 22. 30.01 23. 30.01 24. 30.01			
		25. 30.01 26. 30.01 27. 30.01 28. 30.01			
		29. 30.01 30. 30.01 31. 30.01 32. 30.01			
		33. 30.01 34. 30.01 35. 30.01 36. 30.01			
		37. 30.01 38. 30.01 39. 30.01 40. 30.01			
		41. 30.01 42. 30.01 43. 30.01 44. 30.01			
		45. 30.01 46. 30.01 47. 30.01 48. 30.01			
		49. 30.01 50. 30.01 51. 30.01 52. 30.01			
		53. 30.01 54. 30.01 55. 30.01 56. 30.01			
		57. 30.01 58. 30.01 59. 30.01 60. 30.01			
		61. 30.01 62. 30.01 63. 30.01 64. 30.01			
		65. 30.01 66. 30.01 67. 30.01 68. 30.01			
		69. 30.01 70. 30.01 71. 30.01 72. 30.01			
		73. 30.01 74. 30.01 75. 30.01 76. 30.01			
		77. 30.01 78. 30.01 79. 30.01 80. 30.01			
		81. 30.01 82. 30.01 83. 30.01 84. 30.01			
		85. 30.01 86. 30.01 87. 30.01 88. 30.01			
		89. 30.01 90. 30.01 91. 30.01 92. 30.01			
		93. 30.01 94. 30.01 95. 30.01 96. 30.01			
		97. 30.01 98. 30.01 99. 30.01 100. 30.01			
		101. 30.01 102. 30.01 103. 30.01 104. 30.01			
		105. 30.01 106. 30.01 107. 30.01 108. 30.01			
		109. 30.01 110. 30.01 111. 30.01 112. 30.01			
		113. 30.01 114. 30.01 115. 30.01 116. 30.01			
		117. 30.01 118. 30.01 119. 30.01 120. 30.01			
		121. 30.01 122. 30.01 123. 30.01 124. 30.01			
		125. 30.01 126. 30.01 127. 30.01 128. 30.01			
		129. 30.01 130. 30.01 131. 30.01 132. 30.01			
		133. 30.01 134. 30.01 135. 30.01 136. 30.01			
		137. 30.01 138. 30.01 139. 30.01 140. 30.01			
		141. 30.01 142. 30.01 143. 30.01 144. 30.01			
		145. 30.01 146. 30.01 147. 30.01 148. 30.01			
		149. 30.01 150. 30.01 151. 30.01 152. 30.01			
		153. 30.01 154. 30.01 155. 30.01 156. 30.01			
		157. 30.01 158. 30.01 159. 30.01 160. 30.01			
		161. 30.01 162. 30.01 163. 30.01 164. 30.01			
		165. 30.01 166. 30.01 167. 30.01 168. 30.01			
		169. 30.01 170. 30.01 171. 30.01 172. 30.01			
		173. 30.01 174. 30.01 175. 30.01 176. 30.01			
		177. 30.01 178. 30.01 179. 30.01 180. 30.01			
		181. 30.01 182. 30.01 183. 30.01 184. 30.01			
		185. 30.01 186. 30.01 187. 30.01 188. 30.01			
		189. 30.01 190. 30.01 191. 30.01 192. 30.01			
		193. 30.01 194. 30.01 195. 30.01 196. 30.01			
		197. 30.01 198. 30.01 199. 30.01 200. 30.01			
		201. 30.01 202. 30.01 203. 30.01 204. 30.01			
		205. 30.01 206. 30.01 207. 30.01 208. 30.01			
		209. 30.01 210. 30.01 211. 30.01 212. 30.01			
		213. 30.01 214. 30.01 215. 30.01 216. 30.01			
		217. 30.01 218. 30.01 219. 30.01 220. 30.01			
		221. 30.01 222. 30.01 223. 30.01 224. 30.01			
		225. 30.01 226. 30.01 227. 30.01 228. 30.01			
		229. 30.01 230. 30.01 231. 30.01 232. 30.01			
		233. 30.01 234. 30.01 235. 30.01 236. 30.01			
		237. 30.01 238. 30.01 239. 30.01 240. 30.01			
		241. 30.01 242. 30.01 243. 30.01 244. 30.01			
		245. 30.01 246. 30.01 247. 30.01 248. 30.01			
		249. 30.01 250. 30.01 251. 30.01 252. 30.01			
		253. 30.01 254. 30.01 255. 30.01 256. 30.01			
		257. 30.01 258. 30.01 259. 30.01 260. 30.01			
		261. 30.01 262. 30.01 263. 30.01 264. 30.01			
		265. 30.01 266. 30.01 267. 30.01 268. 30.01			
		269. 30.01 270. 30.01 271. 30.01 272. 30.01			
		273. 30.01 274. 30.01 275. 30.01 276. 30.01			
		277. 30.01 278. 30.01 279. 30.01 280. 30.01			
		281. 30.01 282. 30.01 283. 30.01 284. 30.01			
		285. 30.01 286. 30.01 287. 30.01 288. 30.01			
		289. 30.01 290. 30.01 291. 30.01 292. 30.01			
		293. 30.01 294. 30.01 295. 30.01 296. 30.01			
		297. 30.01 298. 30.01 299. 30.01 300. 30.01			
		301. 30.01 302. 30.01 303. 30.01 304. 30.01			
		305. 30.01 306. 30.01 307. 30.01 308. 30.01			
		309. 30.01 310. 30.01 311. 30.01 312. 30.01			
		313. 30.01 314. 30.01 315. 30.01 316. 30.01			
		317. 30.01 318. 30.01 319. 30.01 320. 30.01			
		321. 30.01 322. 30.01 323. 30.01 324. 30.01			
		325. 30.01 326. 30.01 327. 30.01 328. 30.01			
		329. 30.01 330. 30.01 331. 30.01 332. 30.01			
		333. 30.01 334. 30.01 335. 30.01 336. 30.01			
		337. 30.01 338. 30.01 339. 30.01 340. 30.01			
		341. 30.01 342. 30.01 343. 30.01 344. 30.01			
		345. 30.01 346. 30.01 347. 30.01 348. 30.01			
		349. 30.01 350. 30.01 351. 30.01 352. 30.01			
		353. 30.01 354. 30.01 355. 30.01 356. 30.01			
		357. 30.01 358. 30.01 359. 30.01 360. 30.01			
		361. 30.01 362. 30.01 363. 30.01 364. 30.01			
		365. 30.01 366. 30.01 367. 30.01 368. 30.01			
		369. 30.01 370. 30.01 371. 30.01 372. 30.01			
		373. 30.01 374. 30.01 375. 30.01 376. 30.01			
		377. 30.01 378. 30.01 379. 30.01 380. 30.01			
		381. 30.01 382. 30.01 383. 30.01 384. 30.01			
		385. 30.01 386. 30.01 387. 30.01 388. 30.01			
		389. 30.01 390. 30.01 391. 30.01 392. 30.01			
		393. 30.01 394. 30.01 395. 30.01 396. 30.01			
		397. 30.01 398. 30.01 399. 30.01 400. 30.01			
		401. 30.01 402. 30.01 403. 30.01 404. 30.01			
		405. 30.01 406. 30.01 407. 30.01 408. 30.01			
		409. 30.01 410. 30.01 411. 30.01 412. 30.01			
		413. 30.01 414. 30.01 415. 30.01 416. 30.01			
		417. 30.01 418. 30.01 419. 30.01 420. 30.01			
		421. 30.01 422. 30.01 423. 30.01 424. 30.01			
		425. 30.01 426. 30.01 427. 30.01 428. 30.01			
		429. 30.01 430. 30.01 431. 30.01 432. 30.01			
		433. 30.01 434. 30.01 435. 30.01 436. 30.01			
		437. 30.01 438. 30.01 439. 30.01 440. 30.01			
		441. 30.01 442. 30.01 443. 30.01 444. 30.01			
		445. 30.01 446. 30.01 447. 30.01 448. 30.01			
		449. 30.01 450. 30.01 451. 30.01 452. 30.01			
		453. 30.01 454. 30.01 455. 30.01 456. 30.01			
		457. 30.01 458. 30.01 459. 30.01 460. 30.01			
		461. 30.01 462. 30.01 463. 30.01 464. 30.01			
		465. 30.01 466. 30.01 467. 30.01 468. 30.01			
		469. 30.01 470. 30.01 471. 30.01 472. 30.01			
		473. 30.01 474. 30.01 475. 30.01 476. 30.01			
		477. 30.01 478. 30.01 479. 30.01 480. 30.01			
		481. 30.01 482. 30.01 483. 30.01 484. 30.01			
		485. 30.01 486. 30.01 487. 30.01 488. 30.01			
		489. 30.01 490. 30.01 491. 30.01 492. 30.01			
		493. 30.01 494. 30.01 495. 30.01 496. 30.01			
		497. 30.01 498. 30.01 499. 30.01 500. 30.01			
		501. 30.01 502. 30.01 503. 30.01 504. 30.01			
		505. 30.01 506. 30.01 507. 30.01 508. 30.01			
		509. 30.01 510. 30.01 511. 30.01 512. 30.01			
		513. 30.01 514. 30.01 515. 30.01 516. 30.01			
		517. 30.01 518. 30.01 519. 30.01 520. 30.01			
		521. 30.01 522. 30.01 523. 30.01 524. 30.01			
		525. 30.01 526. 30.01 527. 30.01 528. 30.01			
		529. 30.01 530. 30.01 531. 30.01 532. 30.01			
		533. 30.01 534. 30.01 535. 30.01 536. 30.01			
		537. 30.01 538. 30.01 539. 30.01 540. 30.01			
		541. 30.01 542. 30.01 543. 30.01 544. 30.01			
		545. 30.01 546. 30.01 547. 30.01 548. 30.01			
		549. 30.01 550. 30.01 551. 30.01 552. 30.01			
		553. 30.01 554. 30.01 555. 30.01 556. 30.01			
		557. 30.01 558. 30.01 559. 30.01 560. 30.01			
		561. 30.01 562. 30.01 563. 30.01 564. 30.01			
		565. 30.01 566. 30.01 567. 30.01 568. 30.01			
		569. 30.01 570. 30.01 571. 30.01 572. 30.01			
		573. 30.01 574. 30.01 575. 30.01 576. 30.01			
		577. 30.01 578. 30.01 579. 30.01 580. 30.01			
		581. 30.01 582. 30.01 583. 30.01 584. 30.01			
		585. 30.01 586. 30.01 587. 30.01 588. 30.01			
		589. 30.01 590. 30.01 591. 30.01 592. 30.01			
		593. 30.01 594. 30.01 595. 30.01 596. 30.01			
		597. 30.01 598. 30.01 599. 30.01 600. 30.01			
		601. 30.01 602. 30.01 603. 30.01 604. 30.01			
		605. 30.01 606. 30.01 607. 30.01 608. 30.01			
		609. 30.01 610. 30.01 611. 30.01 612. 30.01			
		613. 30.01 614. 30.01 615. 30.01 616. 30.01			
		617. 30.01 618. 30.01 619. 30.01 620. 30.01			
		621. 30.01 622. 30.01 623. 30.01 624. 30.01			
		625. 30.01 626. 30.01 627. 30.01 628. 30.01			
		629. 30.01 630. 30.01 631. 30.01 632. 30.01			
		633. 30.01 634. 30.01 635. 30.01 636. 30.01			
		637. 30.01 638. 30.01 639. 30.01 640. 30.01			
		641. 30.01 642. 30.01 643. 30.01 644. 30.01			
		645. 30.01 646. 30.01 647. 30.01 648. 30.01			
		649. 30.01 650. 30.01 651. 30.01 652. 30.01			
		653. 30.01 654. 30.01 655. 30.01 656. 30.01			
		657. 30.01 658. 30.01 659. 30.01 660. 30.01			
		661. 30.01 662. 30.01 663. 30.01 664. 30.01			
		665. 30.01 666. 30.01 667. 30.01 668. 30.01			
		669. 30.01 670. 30.01 671. 30.01 672. 30.01			
		673. 30.01 674. 30.01 675. 30.01 676. 30.01			
		677. 30.01 678. 30.01 679. 30.01 680. 30.01			
		681. 30.01 682. 30.01 683. 30.01 684. 30.0			

NOTES:

1	CLOSE SYSTEM VENT VALVE.
2	OPEN VALVE TO VACUUM GAUGE.
3	OPEN BLEEDER VALVE TO START ROUGH OUT PURGE.

SYMBOLS	
	THERMOCOUPLE GAUGE 
	IONIZATION GAUGE 
	OPEN VALVE 
	CLOSED VALVE 
	VACUUM GAUGE 
	PRESSURE GAUGE 



REFERENCE ONLY	UNITS: MILLIMETER, INCHES AND SUBDIVISIONS THEREOF METRIC (mm) ARE IN PARENTHESES		DATE	C. C. E.	
	TOLERANCES OF FRACTIONS 3/64 AND TOLERANCES OF DECIMALS		DRAWN B.V.M.	GAP PRESSURIZING SEQUENCE	
	X 3/64 3X 3/64 3X 3/64 3X 3/64		CHK		
	1. BREAK EDGES 1/64 MAX				
	2. DO NOT SCALE THIS DRAWING				
	3. ALL DIMENSIONS TO ANGLES Y145 150E				
	4. HALL CALL OUT TO ANNEAL SURFACE				
PART NOT IDENT. AMBY.	THICK DIM		SIZE	CAGE C1	DRAWING NO.
			SCALE 1/8"	02887	MDT610-12
			CONTRACT/JOB NUMBER		REV A
			N60921-93-A-A345		1 OF 4
					2 OF 4
					3 OF 4
					4 OF 4

REFERENCE ONLY	UNLESS INDICATED, SPECIFIED ALL DIMENSIONS ARE IN INCHES METRIC GMD ARE IN PARENTHESES TOLERANCES OF FRACTIONS 3/16 & TOLERANCES OF DECIMALS X .0001 .001 .0005 .0015 1. BREAK EDGES 1/64 MAX 2. DO NOT SCALE THIS DRAWING 3. ALL DIMENSIONS TO CENTER UNLESS 4. MARK ALL HIDDEN SURFACES	DRAWN B.M.M. 12-94 CHKD APPD	DATE 12-94	C. C. E.
REMARKS AND REVISIONS				
REVISION NO. REVISION				
BY DATE				
SCALE N/A	WEIGHT	DRAWING NO. MDT610-14	REV A	SHEET 1 OF 14
APPLICATION				

COOLING SYSTEM

COOLING SYSTEM PARTS LIST

ITEM	DESCRIPTION	MANUFACTURER	QUANTITY	PRICE	EXTENDED 1	EXTENDED 2
1	COOLANT PUMP 5.5 GPM, 15ft HEAD PART # 815-BR113	MARCH	1	\$239.00	\$239.00	
2	HEAT EXCHANGER AIR TO WATER 1KW SERIES 6321	LYTRON	1	\$453.00	\$453.00	
	CFT SERIES CHILLER 10KW PART # CFT-300A	NESLAB	1	\$4,885.00		\$4,885.00
3	METERING VALVE PART # SS-4L	SWAGELOK	1	\$66.00	\$66.00	\$66.00
4	FLOW SENSOR PART # DF-0708SS	KOBOLD	1	\$512.00	\$512.00	\$512.00
5	RESISTIVITY MONITOR PART # H-05970-65	COLE-PARMER	1	\$375.00	\$375.00	\$375.00
6	RESISTIVITY CELL 0-18Meg. PART # H-05970-70	COLE-PARMER	1	\$165.00	\$165.00	\$165.00
7	PREFILTER HOUSING, 10in. PART # H-01508-70	COLE-PARMER	1	\$68.00	\$68.00	\$68.00
	25 MICRON CARTRIDGE PART # H-29802-24		1	\$23.85	\$23.85	\$23.85
8	DEIONIZING FILTER HOUSING 12 5/8IN. PART # H-01503-20	COLE-PARMER	1	\$60.00	\$60.00	\$60.00
	RESIN CANISTOR PART# H-01503-30	COLE- PARMER	1	\$29.70	\$29.70	\$29.70
9	5Gal. RESERVOIR TANK NALGENE w/SPIGOT PART# H-06321-11	COLE-PARMER	1	\$50.50	\$50.50	
10	DIAL GAUGE 0-160PSI PART # H-68006-06	COLE-PARMER	2	\$44.20	\$88.40	\$88.40
11	"50" SERIES CHECK VALVE PART# SS-53S4	SWAGELOK	1	\$60.00	\$60.00	\$60.00
12	"RL3" SERIES PRV PART# SS-RL3S4	SWAGELOK	1	\$121.80	\$121.80	\$121.80
13	THERMOCOUPLE PIPE PLUG PROBE TYPE K, #H-08516-74	COLE-PARMER	4	\$36.00	\$144.00	\$144.00
14	DIGITAL TEMP. METER with ALARM PART # H-92751-20	COLE-PARMER	1	\$362.00	\$362.00	\$362.00
15	SWITCH BOX PART # H-92752-20	COLE-PARMER	1	\$105.00	\$105.00	\$105.00


COOLING SYSTEM PARTS LIST

16	IMPOLENE TUBING 100ft SPOOL	CONSOLIDATED PLASTICS,INC	1	\$50.00	\$50.00	\$50.00
17	REDUCER NIPPLE PART # SS-16-HRN-8	SWAGELOK CAJON	3	\$23.50	\$70.50	\$70.50
18	FEMALE CONNECTOR PART # SS-810-7-4	SWAGELOK	4	\$11.30	\$45.20	\$45.20
19	REDUCING ADAPTER PART # SS-12-RA-8	SWAGELOK CAJON	1	\$17.80	\$17.80	\$17.80
20	UNION TEE PART # SS-400-3	SWAGELOK	4	\$16.20	\$64.80	\$64.80
21	FEMALE BRANCH TEE PART # SS-400-3-4TTF	SWAGELOK	6	\$23.30	\$139.80	\$139.80
22	3/4 IN. NPT FEMALE TEE PART # SS-12-T	SWAGELOK CAJON	1	\$74.30	\$74.30	\$74.30
23	HEX REDUCING NIPPLE PART # SS-12-HRN-4	SWAGELOK CAJON	4	\$13.10	\$52.40	\$52.40
24	1/4 IN. TUBE FEMALE CONNECTOR PART# SS-400-7-4	SWAGELOK	4	\$8.20	\$32.80	\$32.80
25	1/4 IN. TUBE MALE CONNECTOR PART # SS-400-1-4	SWAGELOK	4	\$5.10	\$20.40	\$20.40
				=====	=====	=====
				TOTAL	\$3,491.25	\$7,633.75
					*****	*****

POLYDIMETHYLSILOXANE



SYLTHERM XLT Heat Transfer Fluid



XLT

Product Technical Data

CONTENTS

SYLTHERM XLT [†] Heat Transfer Fluid	3
Fluid Selection Criteria	4
Thermal Stability	4
Corrosivity	7
Flammability and Fire Hazards	7
New System Start-up	8
Health and Safety Considerations	9
Customer Service	9
Fluid Analysis	9
Retrofill	10
Storage and Shelf-life	10
Packaging	10
Properties and Engineering Characteristics	
Physical Properties	10
Saturation Properties	
English Units	11
SI Units	12
Thermal Conductivity	13
Vapor Pressure	14
Viscosity	15
Density	16
Thermal Volumetric Expansion	17
Heat Capacity	18
Heat of Vaporization	19
Compressibility Factor	19
Molecular Weight of Vapor	20
Calculated Specific Heat Ratios for Vapors	20
Typical Liquid Phase Heating Scheme	21
Engineering Data	
Liquid Film Coefficient	22
Frictional Pressure Drops	23

[†]Trademark of Dow Corning Corporation

SYLTHERM XLT HEAT TRANSFER FLUID

A Very Low Odor, Long-lasting Heat Transfer Fluid That's Ideal for Batch Processing

SYLTHERM XLT[†] heat transfer fluid is a specially formulated, high performance silicone polymer designed for use as a low temperature, liquid phase heat transfer medium. With a recommended use temperature range of -100°F to 500°F, SYLTHERM XLT fluid offers outstanding low temperature heat transfer and pumpability, plus excellent thermal stability. In addition, SYLTHERM XLT fluid has essentially no odor, is low in acute oral toxicity, and is not listed as reportable under SARA Title III, Section 313.¹ These features make SYLTHERM XLT fluid a viable alternative to many organic heat transfer fluids, chlorinated solvents, and CFCs that are presently used for low temperature, liquid phase service.


At -100°F, the viscosity of SYLTHERM XLT heat transfer fluid is only 12.6 centipoise. A low viscosity at low operating temperatures is a critical

property because it allows high heat transfer coefficients with low pressure drops and pumping horsepower.

The -100°F to 500°F operating range of SYLTHERM XLT fluid makes it ideal for single fluid process heating and cooling applications (batch processing). Single fluid processing with SYLTHERM XLT fluid eliminates process interruption and the loss of temperature control associated with multiple fluid systems. Batch processing with SYLTHERM XLT fluid also eliminates system flush requirements associated with steam/brine and steam/glycol systems. SYLTHERM XLT fluid is noncorrosive toward metals and alloys commonly found in heat transfer systems.

In addition to the performance advantages of SYLTHERM XLT fluid, Dow's supporting services are unequaled. They include technical backup in the design phase, during operation, and after shutdown. Moreover, free analytical testing is provided to monitor fluid condition.

Figure 1—Dimethyl Polysiloxane Molecule



[†]Trademark of Dow Corning Corporation

¹You may need to comply with similar or additional legislation in other countries. Contact your Dow representative for information.

FLUID SELECTION CRITERIA

When evaluating thermal fluids for specific applications, a variety of characteristics should be considered. Four of the most important are thermal stability, human health and environmental regulatory status, freeze point, and viscosity.

Stability

SYLTHERM XLT fluid offers excellent thermal stability at temperatures between -100°F and 500°F. The maximum recommended film temperature is 550°F.

Within its recommended use range, SYLTHERM XLT heat transfer fluid will not degrade to form solids or volatile compounds having substantially higher vapor pressures. As a result, system downtime for periodic fluid reprocessing and replacement is eliminated. SYLTHERM XLT fluid can tolerate occasional high-temperature upsets with only minimal change to the physical properties of the fluid. However, extended use at bulk temperatures above 500°F or film temperatures greater than 550°F, has the potential to generate higher system pressures and cause polymer cross-linking to occur. This will eventually cause the viscosity of the fluid to increase to a point where replacement will be required to restore system performance.

¹You may need to comply with similar or additional legislation in other countries. Contact your Dow representative for information.

Low Odor, Non-reportable

SYLTHERM XLT fluid is virtually odorless and is low in acute oral toxicity. In addition, it is not listed as reportable under SARA Title III, Section 313.¹ SYLTHERM XLT fluid is well suited for use in pharmaceutical, fine chemical, and other processes where these properties are desired.

Freeze Point

SYLTHERM XLT fluid remains liquid below -100°F (freeze point is -168°F). This eliminates many of the problems associated with cold weather start-ups and shutdowns. Steam or electrical tracing, which is costly to install and operate, is not needed.

Viscosity

The excellent viscosity characteristics of SYLTHERM XLT fluid at low temperatures make it an efficient choice for very low temperature applications. The low viscosity of SYLTHERM XLT fluid at low temperatures (only 12.6 cps at -100°F) minimizes pressure drop and reduces pumping horsepower requirements. In addition, high heat transfer coefficients can be obtained over the fluid's entire temperature range. This can reduce refrigeration equipment energy consumption and cut process heat exchanger surface area requirements.

Thermal Stability

The thermal stability of a heat transfer fluid is dependent not only on its chemical structure but also on the design and operating temperature profile of the system in which it is used. Maximum fluid life can be obtained by following sound engineering practices in the design of the heat transfer system. Three key areas of focus are: designing and operating

the heater and/or energy recovery unit, preventing chemical contamination, and eliminating contact of the fluid with air.

When units are operated at high temperatures, fluid velocity in fired heaters should be a minimum of 6 feet per second; a range of 6 to 12 feet per second should cover most cases. The actual velocity selected will depend on an economic balance between the cost of circulation and heat transfer surface. Operating limitations are usually placed on heat flux by equipment manufacturers. This heat flux is determined for a maximum film temperature by the operating conditions of the particular unit.

Heater Design and Operation

Poor design and/or operation of the fired heater can cause overheating, resulting in excessive thermal degradation of the fluid. Some problem areas to be avoided include:

1. Flame impingement.
2. Operating the heater above its rated capacity.
3. Modifying the fuel-to-air mixing procedure to change the flame height and pattern. This can yield higher flame and gas temperatures together with higher heat flux.
4. Low fluid velocity/high heat flux areas resulting in excessive heat transfer fluid film temperatures.

The manufacturer of the fired heater should be the primary contact in supplying you with the proper equipment for your heat transfer system needs.

Contamination Effects

SYLTHERM XLT heat transfer fluid is not sensitive to contamination by common piping contaminants, including water (during start-up and dry-out operations), rust, mill scale, lubricants, pipe dope, and small amounts of solvent and organic heat transfer fluid residue. SYLTHERM XLT fluid is somewhat more sensitive to contamination by acids or bases at elevated temperatures. As a result, lower molecular weight cyclic siloxanes can form and can raise the freeze point of the fluid. Similarly, contamination by water, oxygen, or other oxidants when the fluid is at an elevated temperature can result in cross-linking of polymer molecules and, if not corrected, can cause a gradual increase in viscosity. In order to minimize the likelihood of oxygen contamination, the system expansion tank should have an inert gas (such as nitrogen) blanket.

Expansion Tank

Figure 2 (page 6) is a simplified schematic of a recommended system loop design for SYLTHERM XLT heat transfer fluid. The expansion tank is positioned at the highest point in the system and has the capability for full flow of the heat transfer fluid through the tank. This design allows the expansion tank to be the lowest pressure point in the system, and the constant flow of heat transfer fluid through the tank ensures that vapors form only in the expansion tank. Once the system is heated up to the appropriate temperature and operating normally, system pressure will slowly increase until either the pressure in the expansion tank reaches

the setting on the back pressure regulator valve, or the system reaches the vapor pressure for the temperature of the fluid in the expansion tank. When the back pressure regulator is set at a pressure lower than the equilibrium vapor pressure of the fluid for a given temperature, periodic venting of the volatile materials will take place. The fluid will suffer no deleterious effect; however, periodic additions of fluid will be needed to maintain system volume.

An inert gas (such as nitrogen) blanket on the expansion tank is required to prevent the fluid from coming into contact with the outside air. Without this inert gas blanket, humid, outside air is likely to be drawn into the tank whenever the system cools below its normal operating temperature. This moisture contamination can result in increased pressure in the system due to steam formation on the next heat-up cycle or form ice in refrigeration equipment during low temperature operation. To avoid this, the inert gas supply regulator should be adjusted and maintained at a low setting (3–5 psig). This will minimize both the inert gas consumption and the additive effects of the blanket gas on total system pressure.


To prevent pump cavitation, the fluid pressure at the entrance to the pump must be above its vapor pressure, and there must be sufficient head in addition to the vapor pressure to satisfy the Net Positive Suction Head (NPSH) requirements of the pump. If the expansion tank is designed as shown in Figure 2, the back pressure regulator setting on the expansion tank will control the pressure at the entrance to the pump. The regulator set point should be 10 to 15 psi above the vapor pressure corresponding to the fluid temperature in the expansion tank.

NPSH requirements are primarily satisfied by the elevation of the expansion tank. The elevation is determined by calculating the total head necessary to overcome frictional line losses and specific NPSH requirements of the pump. In systems where such tank elevation is not practical, NPSH requirements can be met by increasing the amount of the blanket gas (usually nitrogen) in the vapor space of the expansion tank, thereby increasing the overall pressure in the tank. However, the additional system pressure created by the nitrogen should be accounted for during the system design.

The expansion tank design must satisfy two necessary requirements for proper start-up and operation of the system. First, the system piping to the expansion tank should be designed to permit full flow of fluid through the tank. A double drop leg design (see Figure 2) is the most effective arrangement to remove air, water vapors, and other noncondensibles during system start-up. For ongoing operation, flow of fluid through the tank can often be reduced as long as sufficient flow is maintained to prevent pump cavitation. The tank and connecting piping should also be insulated to prevent the condensation of any vapors that may accumulate in this portion of the system.

Second, the inert gas blanket on the expansion tank should allow for a continuous flow of inert gas to be purged through the vapor space during the initial start-up. Separate inert gas supply and discharge nozzles, spaced as far apart as possible, will help ensure that any volatile contaminants (such as water or solvents) will be swept from the system during initial start-up.

Figure 2—Simplified System Schematic for SYLTHERM XLT Heat Transfer Fluid



The vent lines from the safety relief valve and back pressure regulator should be discharged to a safe area away from open flame and other potential sources of ignition. An appropriate outside container located well away from building air-intake fans is recommended. The vented volatile materials will be typically classified as flammable.

The expansion tank should be sized so that it is approximately $\frac{1}{4}$ full when the system is at ambient temperature, and $\frac{3}{4}$ full when the system is at its maximum operating temperature. Expansion tank instrumentation and fittings must meet the design requirements of the anticipated operating temperatures and pressures of the system and should include (refer to Figure 2):

1. Electronic level gauge covering the full fluid level range.
2. Fluid temperature indicator.
3. Level alarm (high/low) with low level shutdown to protect pump.
4. Pressure indicator with high pressure alarm.

Corrosivity

SYLTHERM XLT heat transfer fluid is noncorrosive toward common metals and alloys used in heat transfer systems, as long as it remains uncontaminated. Even at the high temperatures involved, equipment usually exhibits excellent service life.

Carbon steel is used predominantly in heat transfer systems utilizing SYLTHERM XLT fluid, although low

alloy steels, stainless steels, monel alloys, etc., are also used in miscellaneous pieces of equipment and instruments.

Most corrosion problems are caused by chemicals introduced into the system during cleaning or from process leaks. The severity and nature of the corrosivity will depend upon the amounts and type of contamination involved.

When special materials of construction are used, extra precaution should be taken to avoid contaminating materials containing the following:

<i>Construction Material</i>	<i>Contaminant</i>
<i>Austenitic Stainless Steel</i>	<i>Chlorides</i>
<i>Nickel</i>	<i>Sulfur</i>
<i>Copper Alloys</i>	<i>Ammonia</i>

Flammability and Fire Hazards

SYLTHERM XLT heat transfer fluid is a combustible material with a flash point of 116°F, a fire point of 140°F (C.O.C.), and an autoignition temperature of 662°F (ASTM Method D-2155).

Vapor leaks to the atmosphere are sometimes encountered. Such leaks, however small, should not be tolerated because of the cost of replacing lost medium. Experience has shown that leaking vapors have usually cooled well below the fire point, and fire has rarely resulted.

Leaks from flanges or valves into insulation are also potentially hazardous because they can lead to fires in the insulation. It has been found, for example, that leakage of organic

materials into some types of insulation at elevated temperatures may result in spontaneous ignition due to auto-oxidation.

Vapors of SYLTHERM XLT fluid do not pose a serious flammability hazard at room temperature because the saturation concentration is so far below the lower flammability limit that ignition is extremely unlikely. Flammable mists are, however, possible under unusual circumstances where the time of exposure to an ignition source, the temperature of the source and the atmosphere, the volume of mixture, the fuel-air ratio, and the mist particle size all fall within a somewhat narrow range.

Static Spark Hazard

Heat transfer fluids like SYLTHERM XLT heat transfer fluid are generally poor electrical conductors, which means they can build up static charges and discharge static electricity within vessels or while being drained out of vessels. Therefore, safe engineering practice dictates that oxygen must be excluded from the headspace of the expansion tank. Similar precautions concerning static sparks should be taken when loading and unloading used fluid and volatiles.

Flammable-gas Detectors

Silicone vapors can deactivate many brands of flammable-gas detectors. However, several manufacturers offer detectors for silicone environments and report the operating life of these detectors is not affected by the presence of silicone materials. Contact your Dow Technical Service representative at 1-800-447-4369 for listings of suppliers of these detectors.

NEW SYSTEM START-UP

The following information is a brief summary of the general recommendations and procedures for starting up a system with SYLTHERM XLT heat transfer fluid.

Prior to start-up, the system must be cleaned of dirt, welding slag, and other miscellaneous debris. Extra care taken to keep the system clean during construction can eliminate extensive cleaning prior to start-up. As mentioned previously, it is also very important to remove any residual water from the system prior to the installation of SYLTHERM XLT heat transfer fluid.

Because the design of all heat transfer systems differs to some extent, a detailed set of start-up procedures covering all possible systems is not practical. Users should develop procedures based on their own internal standards and recommendations from heat transfer equipment suppliers. The following procedures are presented as general guidelines only.

1. If the system is flushed with water or a suitable solvent, be sure that the fluid is circulated sufficiently through the system to pick up any remaining oils and debris. The pump and suction strainer should be checked periodically during this time to ensure that any collected debris is not severely restricting fluid flow to the pump inlet. If a filter is installed, filter the fluid for as long as practical through a 10-micron filter.
2. Completely drain the flush fluid by pressurizing the system with nitrogen or dry air, and opening all low-point drains. Alternately open and close all drain valves to increase the velocity of the gas flow. This will help to remove residual water/solvent and loose foreign particles.
3. Fill the system with SYLTHERM XLT heat transfer fluid. Circulate the fluid cold. Check for and repair any leaks. If a flush fluid was not used, check the pump suction strainers for any collected solids. If a filter is installed, continue circulating the fluid through the filter until the upper temperature limit of the filter is approached.
4. For the initial stages of start-up, the inert gas blanket system on the expansion tank should be arranged to allow a steady purge (1-2 scfm) of gas to sweep through the vapor space of the tank. At the same time, the valves controlling fluid flow should be set so that the maximum amount of fluid flows through the expansion tank.
5. Increase the fluid temperature to 250°F as measured at the heater outlet. The rate of increase should be held to 100°F per hour or the maximum recommended for the various pieces of equipment in the system, whichever is lower. This will allow the equipment to be brought up to temperature safely and enable start-up personnel to check for leaks and ensure that all instrumentation is operating properly. Maintain the 250°F temperature until the amount of steam or solvent vapors exiting the vent line from the expansion tank has subsided. This may require several hours.
6. Raise the fluid temperature to 300°F and repeat the procedure described previously until venting has again subsided. Repeat the procedure once more at 350°F.

It is essential that sufficient flow of fluid be maintained through the expansion tank during these steps so that the temperature in the tank is high enough to boil out any residual moisture or solvents from the system.
7. Set the nitrogen supply regulator in the range of 3 to 5 psig. Engage the back pressure regulator at the specified design pressure. No further venting will occur unless the pressure in the expansion tank exceeds the specified pressure. Any further pressure increase in the tank should only result from compression of the inert gas by the expanding fluid or from the generation of volatile materials by SYLTHERM XLT heat transfer fluid. Any additional inert gas should enter the tank only when the tank pressure falls below the 3 to 5 psig setting (e.g., as it would if the system were to be shut down).

For systems which operate primarily at low temperatures, and do not have the capability of heating the fluid to the temperatures outlined above, other methods of water removal may be required. The use of molecular sieves or ion exchange resins to remove the water from the fluid may be necessary.

HEALTH AND SAFETY CONSIDERATIONS

A Material Safety Data Sheet (MSDS) for SYLTHERM XLT heat transfer fluid is available by contacting your nearest Dow sales representative, or by calling 1-800-447-4369. The MSDS contains complete health and safety information regarding the use of this product. Read and understand the MSDS before handling or otherwise using this product.

SYLTHERM XLT heat transfer fluid has been studied for acute toxicological properties under the Federal Hazardous Substance Act guidelines. As a result of the FHSA study, SYLTHERM XLT heat transfer fluid has been classified as:

- Nontoxic, with regard to acute oral ingestion or dermal absorption to quantities typically contacted during normal use
- Having minimal potential for eye or skin irritation

Additionally, studies indicate that repeated, prolonged skin contact should not result in irritation. Normal industrial handling procedures are adequate to handle this product.

Unlike many low temperature heat transfer fluids, SYLTHERM XLT fluid has minimal odor and no airborne exposure limits. However, vapors of SYLTHERM XLT heat transfer fluid released into the air at temperatures above 300°F (149°C) may cause some temporary eye and/or respiratory irritation due to the partial oxidation of the fluid. In areas with adequate ventilation, no special breathing apparatus is required. Prolonged exposures or exposures in poorly ventilated areas with high vapor concentrations should be avoided. The predominant by-products in these vapors are low-molecular-weight dimethylsiloxanes. These cyclic and linear siloxanes are commonly used in such personal care products as cosmetics and deodorants.

Leaks or spills of SYLTHERM XLT heat transfer fluid into soil typically result in the gradual break down of the polymer to form naturally occurring materials like silica, water, and carbon dioxide.

CUSTOMER SERVICE FOR USERS OF SYLTHERM XLT HEAT TRANSFER FLUID

Fluid Analysis

The Dow Chemical Company offers an analytical service for SYLTHERM XLT heat transfer fluid. It is recommended that users send a one-pint representative sample at least annually to:

Testing Section for DOWTHERM
and SYLTHERM Fluids
The Dow Chemical Company
Larkin Laboratory/2040 Receiving
Midland, Michigan 48674

This analysis gives a profile of fluid changes to help ensure against trouble from product contamination.

When a sample is taken from a hot system it should be cooled to below 100°F before it is put into the shipping container. Cooling the sample below 100°F will prevent the possibility of thermal burns to personnel; also, the fluid is then below its flash point. In addition, any low boilers will not flash and be lost from the sample. Cooling can be done by either a batch or continuous process. The batch method consists of isolating the hot sample of fluid from the system in a properly designed sample collector and then cooling it to below 100°F. After it is cooled, it can be withdrawn from the sampling collector into a container for shipment.

The continuous method consists of controlling the fluid at a very low rate through a steel or stainless steel cooling coil so as to maintain it at 100°F or lower as it comes out of the end of the cooler into the sample collector. Before a sample is taken, the sampler should be thoroughly flushed. This initial fluid should be returned to the system or disposed of in a safe manner.

It is important that samples sent for analysis be representative of the charge in the unit. Ordinarily, samples should be taken from the main circulating line of a fluid system. Occasionally, additional samples may have to be taken from other parts of the system where specific problems exist.

Retrofill

SYLTHERM XLT heat transfer fluid has successfully replaced organic fluids in existing heat transfer systems. However, there are engineering considerations that should be addressed due to the unique characteristics of SYLTHERM XLT heat transfer fluid. It is suggested that The Dow Chemical Company be consulted in advance of fluid purchase and installation to discuss how best to optimize fluid performance in your system.

Table 1—Physical Properties of SYLTHERM XLT Heat Transfer Fluid¹

Appearance	Crystal Clear Liquid
Viscosity at 77°F (25°C), cps	1.4
Flash Point ² , Closed Cup, Typical	116°F (47°C)
Flash Point ³ , Open Cup, Typical	130°F (54°C)
Autoignition Point, ASTM D-2155	662°F (350°C)
Acid Number, Typical	0.01
Freeze Point	-168°F (-111°C)
Density at 77°F (25°C), lb/gal	7.1
Specific Gravity at 77°F (25°C)	0.85
Heat of Combustion, Btu/lb	14,100
Average Molecular Weight	317
Pseudo Critical Constants, T _c P _c , atm	620°F (327°C) 12

¹Not to be construed as specifications.

²ASTM D92

³ASTM D93

Storage and Shelf-life

Dow Corning Corporation certifies that SYLTHERM XLT heat transfer fluid, when stored in its original container, will meet sales specification requirements for a period of 24 months from date of shipment.

Store fluid at ambient temperature.

NOTE: If outside storage of drums is planned, it is suggested that some type of removable drum cover be used to prevent water from entering the drum through the bung seal.

Packaging

SYLTHERM XLT heat transfer fluid is routinely supplied in 35-lb (16-kg), 375-lb (170-kg) containers (net weight) and in bulk quantities.

Table 2—Saturation Properties of SYLTHERM XLT Fluid (English Units)

Temp. °F	Density lb/ft ³	Specific Heat Btu/(lb)(°F)	Therm. Cond. Btu/(hr)(ft ² °F/ft)	Viscosity cps	Vap. Press. psia
-100	57.76	0.337	0.0748	12.6	0.0
-80	57.17	0.344	0.0736	8.8	0.0
-60	56.58	0.351	0.0724	6.4	0.0
-40	55.99	0.357	0.0711	4.8	0.0
-20	55.39	0.364	0.0699	3.7	0.0
0	54.80	0.371	0.0686	2.9	0.0
20	54.20	0.378	0.0673	2.3	0.0
40	53.60	0.385	0.0659	1.9	0.0
60	52.99	0.391	0.0646	1.6	0.0
80	52.37	0.398	0.0632	1.3	0.0
100	51.75	0.405	0.0618	1.1	0.1
120	51.11	0.412	0.0603	1.0	0.1
140	50.46	0.419	0.0589	0.86	0.2
160	49.80	0.426	0.0574	0.75	0.4
180	49.12	0.432	0.0559	0.67	0.7
200	48.43	0.439	0.0544	0.60	1.2
220	47.72	0.446	0.0528	0.54	1.8
240	46.99	0.453	0.0513	0.49	2.7
260	46.24	0.460	0.0497	0.44	3.9
280	45.47	0.466	0.0481	0.40	5.5
300	44.68	0.473	0.0465	0.37	7.5
320	43.86	0.480	0.0449	0.34	10.2
340	43.02	0.487	0.0432	0.32	13.5
360	42.15	0.494	0.0416	0.29	17.5
380	41.25	0.500	0.0399	0.28	22.4
400	40.32	0.507	0.0382	0.26	28.3
420	39.37	0.514	0.0365	0.24	35.3
440	38.38	0.521	0.0348	0.23	43.4
460	37.35	0.528	0.0330	0.22	52.8
480	36.29	0.535	0.0313	0.20	63.6
500	35.20	0.541	0.0295	0.19	75.9
520	34.06	0.548	0.0277	0.18	89.8
540	32.89	0.555	0.0259	0.17	105.3

Table 3—Saturation Properties of SYLTHERM XLT Fluid (SI Units)

Temp. °C	Density kg/m ³	Specific Heat kJ/(kg)(K)	Therm. Cond. W/(m)(K)	Viscosity (mPa)(s)	Vap. Press. kPa
-73	923.91	1.411	0.1294	12.44	0.0
-70	921.35	1.418	0.1288	11.26	0.0
-60	912.81	1.444	0.1269	8.25	0.0
-50	904.30	1.470	0.1251	6.21	0.0
-40	895.78	1.495	0.1231	4.80	0.0
-30	887.26	1.521	0.1212	3.79	0.0
-20	878.71	1.547	0.1192	3.04	0.0
-10	870.11	1.572	0.1171	2.49	0.0
0	861.45	1.598	0.1150	2.07	0.0
10	852.72	1.624	0.1129	1.74	0.0
20	843.89	1.649	0.1108	1.48	0.0
30	834.96	1.675	0.1086	1.27	0.3
40	825.90	1.701	0.1064	1.11	0.6
50	816.71	1.726	0.1042	0.97	1.1
60	807.36	1.752	0.1019	0.86	1.8
70	797.83	1.777	0.0996	0.76	3.0
80	788.12	1.803	0.0973	0.68	4.7
90	778.21	1.829	0.0949	0.62	7.2
100	768.08	1.854	0.0925	0.56	10.6
110	757.71	1.880	0.0901	0.51	15.3
120	747.09	1.906	0.0877	0.47	21.5
130	736.20	1.931	0.0852	0.43	29.7
140	725.03	1.957	0.0827	0.40	40.1
150	713.56	1.983	0.0802	0.37	53.2
160	701.78	2.008	0.0777	0.34	74.6
170	689.67	2.034	0.0751	0.32	89.4
180	677.21	2.060	0.0725	0.30	113.5
190	664.39	2.085	0.0699	0.28	142.2
200	651.19	2.111	0.0673	0.26	176.2
210	637.59	2.137	0.0646	0.25	215.9
220	623.59	2.162	0.0620	0.24	261.9
230	609.16	2.188	0.0593	0.22	314.8
240	594.28	2.214	0.0566	0.21	375.1
250	578.95	2.239	0.0538	0.20	443.5
260	563.15	2.265	0.0511	0.19	520.3
270	546.85	2.291	0.0483	0.18	606.3
280	530.05	2.316	0.0455	0.18	701.8
290	512.73	2.342	0.0427	0.17	807.5

Figure 3—Thermal Conductivity of SYLTHERM XLT Fluid




Figure 4—Vapor Pressure of SYLTHERM XLT Fluid




Figure 5—Absolute Viscosity of SYLTHERM XLT Fluid




Figure 6—Density of SYLTHERM XLT Fluid




Figure 7—Thermal Volumetric Expansion of SYLTHERM XLT Fluid




Figure 8—Heat Capacity of SYLTHERM XLT Fluid




Figure 9—Heat of Vaporization of SYLTHERM XLT Fluid¹





Figure 10—Compressibility Factor (Z) of SYLTHERM XLT Fluid¹



¹ Values are estimated using an equation of state.

Figure 11—Molecular Weight of Vapor of SYLTHERM XLT Fluid¹




Figure 12—Calculated Specific Heat Ratios for Vapors of SYLTHERM XLT Fluid¹




Figure 13—Typical Liquid Phase Heating Scheme
Using SYLTHERM XLT Fluid

Instrument Legend

BA — Burner Alarm
BC — Burner Control
BE — Burner Element (Fire-Eye)
FI — Flow Indicator (Orifice)
FRC — Flow Recording Controller
FSL — Flow Switch Low
LC — Level Controller
PVC — Pressure Control Valve

PI — Pressure Indicator
PIC — Pressure Indicating Controller
PRV — Pressure Relief Valve
PSH — Pressure Switch High
PSL — Pressure Switch Low
TIC — Temperature Indicating Controller
TRC — Temperature Recorder Controller
TSH — Temperature Switch High

— Principal Circuits with SYLTHERM Fluid
— Electrical Lines
— Instrument Air Lines





Figure 14—Liquid Film Coefficient of SYLTHERM XLT Fluid




Sieder and Tate equation
Process Heat Transfer,
D.Q. Kern (1950) p. 103

$$\frac{\bar{h}_i d_i}{k} = 31.06 \left(\frac{d_i G'}{\mu} \right)^{0.8} \left(\frac{C_p \mu}{k} \right)^{1/3} \left(\frac{\mu}{\mu_w} \right)^{0.14}$$

Chart based on $\left(\frac{\mu}{\mu_w} \right)^{0.14} = 1$

Note: The values in this graph are based on the viscosity of fluid as supplied. A reduction in viscosity as the fluid ages at high temperature can increase the coefficient by up to 15%. Contact your Dow TS&D representative if more information is needed.

Figure 15—Frictional Pressure Drops of SYLTHERM XLT Fluid



new product information

Type.	Dimethylsiloxane polymer
Physical Form.	Low-viscosity liquid
Color	Clear
Special Properties	Normal operating range from -100 to 500 F (-73 to 260 C) with film temperatures to 550 F (288 C); is noncorrosive; odorless; essentially non-toxic, and operates in heat transfer systems without fouling
Primary use	Low temperature, liquid-phase heat transfer liquid

SYLTHERM XLT™ Heat Transfer Liquid is a low-viscosity liquid specially designed for use as a low-temperature, liquid-phase heat transfer medium for -100 F to +500 F (-73 to 260 C) service. Its features include:

- * Essentially non-toxic
- * Nonfouling
- * Noncorrosive
- * Odorless
- * Low freeze point
- * Long life

These unique features make it an ideal candidate for single-fluid process heating and cooling systems in the pharmaceutical and fine chemical industries. Syltherm XLT has been designed to provide an environmentally safe, essentially non-toxic and odorless alternative to the organic heat transfer fluids (e.g., water/glycol solutions, diethylbenzene, citrus oils, etc.) that are presently used for this type of service. In addition, the wide operating temperature range and exceptional thermal stability of Syltherm XLT allow it to be used as a replacement for hot oils in many other applications.

The information and data contained herein are based on information we believe reliable. You should thoroughly test any application, and independently conclude satisfactory performance before commercialization. Suggestions of uses should not be taken as inducements to infringe any particular patent.

DOW CORNING CORPORATION, MIDLAND, MICHIGAN 48640 TELEPHONE 517 496-4000

PERFORMANCE

SYLTHERM XLT heat transfer liquid demonstrates exceptional thermal stability over its operational temperature range of -100 F to 500 F. Maximum recommended film temperature is 550 F (288 C). Within its recommended use range, it will not degrade to solids or form any deposits on the inside surfaces of a heat transfer system. SYLTHERM XLT is also noncorrosive to the carbon steel piping and components that are utilized in these systems.

CONTAMINATION

SYLTHERM XLT has been shown not to be sensitive to contamination by common piping contaminants, including water (during start-up and dry-out operations), rust, millscale, lubricants, pipe dope, and small amounts of solvent and organic heat transfer fluid residue. SYLTHERM XLT is somewhat more sensitive to certain types of contamination when at elevated temperatures. Contamination by acids, bases or water can result in the formation of lower molecular weight cyclic siloxanes that can raise the freeze point of the liquid. Contamination by oxygen or other oxidants can result in crosslinking of polymer molecules and, if not corrected, can cause a gradual increase in viscosity. In order to minimize the likelihood of oxygen contamination, the system expansion tank should be provided with an inert gas (e.g. nitrogen) blanket.

TYPICAL PROPERTIES

Note: These values are not intended for use in preparing specifications.

Appearance	Crystal clear liquid
Viscosity at 77 F (25 C), cP	1.6
Flash Point, closed cup, typical	116 F (47 C)
Flash Point, open cup, typical	130 F (54 C)
Autoignition Point, ASTM D-2155	662 F (350 C)
Acid Number, typical	0.01
Freeze Point	< -135 F (-93 C)
Density at 77 F (25 C), lbs/gal	7.1
Specific Gravity at 77 F (25 C)	0.85

Specification Writers: Please contact Dow Corning Corporation, Midland, MI, (517) 496-4000, before writing specifications on this product.

PHYSICAL PROPERTIES OF SYLTHERM XLT HEAT TRANSFER LIQUID

Temperature	Vapor Pressure	Viscosity	Density	Heat Capacity	Thermal Conductivity
F (C)	psia	cP	lbs/ft ³	BTU/lb-F	BTU/hr-ft-F
-100 (-73)	0.00	12.6	57.8	0.336	0.0651
-75 (-59)	0.00	8.13	57.0	0.345	0.0646
-50 (-46)	0.00	5.53	56.3	0.354	0.0641
-25 (-32)	0.00	3.94	55.6	0.362	0.0635
0 (-18)	0.00	2.91	54.9	0.370	0.0630
25 (-4)	0.00	2.22	54.1	0.379	0.0625
50 (10)	0.01	1.74	53.3	0.388	0.0620
75 (24)	0.03	1.40	52.6	0.396	0.0614
100 (38)	0.08	1.14	51.8	0.404	0.0609
125 (52)	0.17	0.952	51.0	0.413	0.0604
150 (66)	0.36	0.805	50.1	0.422	0.0599
175 (79)	0.68	0.689	49.3	0.430	0.0594
200 (93)	1.21	0.598	48.4	0.438	0.0588
225 (107)	2.04	0.524	47.5	0.447	0.0583
250 (121)	3.29	0.463	46.6	0.456	0.0578
275 (135)	5.09	0.413	45.7	0.464	0.0573
300 (149)	7.59	0.371	44.7	0.473	0.0568
325 (163)	10.96	0.336	43.7	0.481	0.0562
350 (177)	15.40	0.306	42.6	0.490	0.0557
375 (191)	21.10	0.280	41.5	0.498	0.0552
400 (204)	28.27	0.258	40.4	0.507	0.0547
425 (218)	37.14	0.238	39.1	0.515	0.0542
450 (232)	47.91	0.222	37.8	0.524	0.0536
475 (246)	60.80	0.207	36.6	0.532	0.0531
500 (260)	76.03	0.193	35.2	0.541	0.0526

REGRESSION EQUATIONS FOR PHYSICAL PROPERTY DATA

The regression equations for SYLTHERM XLT heat transfer liquid are listed below. When using these equations, it is important to preserve the accuracy of the coefficients to ensure the precision of the calculated value.

NOTE: T = degrees Rankine in all equations

Vapor pressure (psia):

$$\text{Natural Log Pressure} = A - B/(T+C) \quad (\text{Antoine Equation})$$

$$\begin{aligned} A &= 11.31412960 \\ B &= 5628.28781546 \\ C &= -154.0 \end{aligned}$$

Viscosity (cP):

$$\text{Natural Log Viscosity} = A + B/T$$

$$\begin{aligned} A &= -4.15321471 \\ B &= 2403.57403897 \end{aligned}$$

Density (lb/ft³):

$$\text{Density} = A + B \cdot T/100 + C \cdot (T/100)^2 + D \cdot (T/100)^3$$

$$\begin{aligned} A &= 70.46750502 \\ B &= -4.43026844 \\ C &= 0.35772178 \\ D &= -0.02906877 \end{aligned}$$

Heat Capacity (BTU/lb-R):

$$\text{Heat Capacity} = A + B \cdot (T/1000)$$

$$\begin{aligned} A &= 0.21423227 \\ B &= 0.34072118 \end{aligned}$$

Thermal Conductivity (BTU/hr-ft-R):

$$\text{Thermal Conductivity} = A + B \cdot (T/1000)$$

$$\begin{aligned} A &= 0.07259731 \\ B &= -0.020838365 \end{aligned}$$

SYSTEM DESIGN INFORMATION

Many system design practices and recommendations found in the following literature are applicable to SYLTHERM XLT:

- * SYLTHERM® 800 Heat Transfer Liquid Design Guide, Form No. 22-964C-88
- * SYLTHERM® 800 Heat Transfer System Design Checklist, Version 2.2, Form No. 24-249-85

NOTE: Some of the information contained in the above literature applies to higher operating temperatures (up to 750 F){399 C} and pressures. Other operating procedures and equipment may be suitable for use with SYLTHERM XLT at low temperatures. Contact the SYLTHERM Technical Support Group for recommendations on specific system design requirements.

SAFE HANDLING INFORMATION

SYLTHERM XLT heat transfer liquid is neither an eye nor skin irritant and contains no OSHA-listed hazardous ingredients. Direct contact with the eye may cause some temporary discomfort, with some redness and dryness similar to the effects of windburn.

MATERIAL SAFETY DATA SHEETS

A Material Safety Data Sheet on SYLTHERM XLT is available on request from Dow Corning Corporation, Midland, MI 48686-0994 and will be supplied with all samples.

PACKAGING

SYLTHERM XLT heat transfer liquid is routinely supplied in 375-lb (170-kg) containers, net weight, and in bulk quantities. One-pound (0.45-kg) samples are available for evaluation and testing.

TECHNICAL SUPPORT AND ASSISTANCE

Dow Corning has a SYLTHERM® Technical Support Group to assist in designing new heat transfer systems or retrofilling existing systems. Dow Corning also provides a fluid monitoring service for users of SYLTHERM XLT heat transfer liquid. The user periodically sends in a representative sample for testing. Results, along with appropriate comments, are reported to ensure top performance. Contact Dow Corning for details or additional technical assistance:

SYLTHERM® Technical Support Group
Mail No. C40B00
P.O. Box 994
Midland, MI 48686-0994 U.S.A

Phone: (517) 496-6000
Telefax: 517-496-5324
Telex: 227450


Product Emergencies: (517) 496-5900

WARRANTY INFORMATION - PLEASE READ CAREFULLY

Dow Corning believes that the information and recommendations in this publication are accurate as of June 1988. Contact Dow Corning for any information published after that date. It is the buyer's responsibility to determine the appropriateness of this product for the buyer's specific end use and to obtain all required clearances. DOW CORNING SPECIFICALLY DISCLAIMS ANY LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES. Suggestions of uses should not be taken as an inducement to infringe any patents.

PUMP STATION

REV	DESCRIPTION	DATE	APPROV



REFERENCE ONLY		UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES METRIC DIMS ARE IN PARENTHESES		DATE		C. C. E.	
		TOLERANCES OF FRACTIONS 1/64	OR			GAS FILL STATION	
		TOLERANCES OF DECIMALS				BLOCK DIAGRAM	
		IN 1/16	IN 1/32	IN 1/64		CASE CODE DRAWING NO. HTD610-22	
						07987	
						SCALE	
						CONTRACT/JOB NUMBER	
						WEIGHT	
						REV	
						A	
						SHEET	
						OF	

GAS FILL PARTS LIST

ITEM	DESCRIPTION	MANUFACTURER	QUANTITY	PRICE	EXTENDED
1	"1" SERIES NEEDLE VALVE W/ BLACK HANDLE PART # SS-1KS4-A-BK	SWAGELOK WHITEY	2	\$55.10	\$110.20
2	"1" SERIES NEEDLE VALVE W/ YELLOW HANDLE PART # SS-1KS4-A-YW	SWAGELOK WHITEY	2	\$55.10	\$110.20
3	"1" SERIES NEEDLE VALVE W/ GREEN HANDLE PART # SS-1KS4-A-GR	SWAGELOK WHITEY	2	\$55.10	\$110.20
4	"1" SERIES NEEDLE VALVE W/ BLUE HANDLE PART # SS-1KS4-A-BL	SWAGELOK WHITEY	2	\$55.10	\$110.20
5	"1" SERIES NEEDLE VALVE W/ RED HANDLE PART # SS-1KS4-A--RD	SWAGELOK WHITEY	1	\$55.10	\$55.10
6	"1" SERIES NEEDLE VALVE W/ ORANGE HANDLI PART # SS-1KS4-A-OG	SWAGELOK WHITEY	1	\$55.10	\$55.10
7	1/4" TUBE TO 1/4" NPT FEMALE BRANCH TEE PART # SS-400-3TTF	SWAGELOK	1	\$19.90	\$19.90
8	1/4 INCH TUBE UNION CROSS PART # SS-400-4	SWAGELOK	4	\$29.30	\$117.20
9	DIFFUSION PUMP 2 INCH. AIR COOLED PART # HSA VNS053	VARIAN	1	\$775.00	\$775.00
10	MECHANICAL VACUUM PUMP, 5.6 SCFM PART # 1402	WELCH	1	\$815.00	\$815.00
11	IONIZATION GAUGE 564 SERIES, 1in. TUBE PART # VNS605	VARIAN	1	\$120.00	\$120.00
12	ION GAUGE CONTROLLER MODEL 880 WITH THERMOCOUPLE GAUGE	VARIAN	1	\$1,295.00	\$1,295.00
13	OVEN, 455 deg. C, 208, 3ph 20x20x20 in. 10KW BLOWER PART # 3804A	LABLINE	1	\$1,250.00	\$1,250.00
14	WORK BENCH WITH DRAWER PART # 53-287AX	C&H	1	\$201.50	\$201.50
15	ASSEMBLY OF GAS FILL STATION	CCE	1	\$600.00	\$600.00
				TOTAL	\$5,744.60
				*****	*****



HSA 2-INCH DIFFUSION PUMP

FEATURES

- Air Cooled . . . no water required for cooling
- High Speed . . . 150 l/s
- High Forepressure Tolerance . . . 0.50 Torr
- Low Backstreaming . . . 0.05 cc/hr. without baffle
- Inlet Baffle . . . optional
- Clean Operation
- Outstanding Reliability and Low Maintenance . . . provided by full fractionating design

AIR-COOLED...HIGH SPEED...VERSATILE

GENERAL DESCRIPTION

The HSA 2-inch air-cooled diffusion pump is an extremely rugged, general purpose pump with a continuous operating range of 2.5×10^{-3} Torr to less than 5×10^{-8} Torr. High pumping speed combined with high forepressure tolerance make the HSA ideal for laboratory or production applications requiring fast cycling.

An exclusive jet and boiler assembly design minimizes the possibility of fluid loss if the pump is exposed to high air pressure. Electrical connectors (male part) are provided for the pump heater and the cooling fan. A five-foot long fan cord is provided for versatility of installation. A large "squirrel cage" blower and copper fins are brazed to the pump body to ensure efficient cooling.

The blower can be rotated around an arc of 270° to facilitate mounting the pump into a system. The cartridge type heater can be easily removed through a port in the side of the heat reflector, eliminating the need for clearance below the pump.




OPTIONAL BAFFLE - COLD CAP

NO INCREASE IN PUMP HEIGHT


For critical applications, an optional conduction-cooled baffle is available. The baffle, which fits into the inlet of the pump, reduces backstreaming so effectively that the residual rate cannot be measured by AVS standards.

SPECIFICATIONS

Speed (unbaffled)	150 ℓ /s at $< 1 \times 10^{-3}$ Torr
(baffled)	60 ℓ /s at $< 3 \times 10^{-3}$ Torr
Normal Operating Range	2×10^{-3} to the 10^{-8} Torr range
Ultimate Pressure	5×10^{-8} Torr (DC-704)
Maximum Forepressure	No Load — 0.5 Torr Full Load — 0.4 Torr
Recommended Forepump	1 CFM (for throughput less than 0.15 Torr ℓ /sec.) 2 CFM (for throughput up to 0.4 Torr ℓ /sec.)
Backstreaming Rate (at inlet flange)	.05 cc/hr. or .02 mg/cm ² /min. unbaffled. With baffle, backstreaming rate not measurable by AVS standard
Warm-up Time	10 minutes
Cooling Time	40 minutes
Fluid Charge	50 cc
Power (heater nominal)	325w, 120v (240v optional)
(blower)	1/30 HP, 120v
Height	13 $\frac{3}{4}$ " (350 mm)
Body	Stainless Steel
Jet Assembly	3 stage, aluminum and brass
Baffle (optional)	Copper — Optically tight, fits inside 3" (76.2 mm) ID inlet of pump
Heater	Removable platen with replaceable cartridge
Weight	16 lbs. including blower



PUMPING SPEED
OF MODEL HSA
DIFFUSION PUMP



HSA Air-cooled Diffusion Pump,
120 V heater and 110 V blower . . . Order No. 0159-85260-301

HSA Air-cooled Diffusion Pump,
240 V heater and 110 V blower . . . Order No. 0159-85260-302

Inlet Baffle . . . Order No. 0181-82291-301

HOW TO ORDER

Orders and requests for additional information should be addressed to the nearest Varian District Office or to Varian Associates, Lexington Vacuum Division, 121 Hartwell Ave., Lexington, Massachusetts 02173. Address European inquiries to nearest Varian District Office or to Varian GmbH, D-7000, Stuttgart-Vaihingen, Breitwiesenstrasse 9, West Germany, or to Varian SpA, Via Varian, 10040 Leini, Torino, Italy.

TRIGGER UNIT

C. C. E.
CUSTOMER: NSWG
TITLE: T-610 TRIGGER GENERATOR
BILL NO: MT610-1

NAME/DATE:
CUSTOMER PO:
CONTRACT NO: N60921-94-C-A345
31-Jan-95

DESIG.	P/N	QTY.	DESCRIPTION	MFR	MFR PART NO.
C1		3	4000pf, 20KVDC CERAMIC CAPACITOR	TDK	UHV-3A
C2			S/A C1		
C3			S/A C1		
C4		5	1300pf, 40KVDC CERAMIC CAPACITOR	TDK	UHV-8A
C5			S/A C4		
C6			S/A C4		
C7			S/A C4		
C8			S/A C4		
C9		4	100pf, 40KVDC CAPACITOR	TDK	UHV-241A
C10			S/A C9		
C11			S/A C9		
C12			S/A C9		
C13		1	2.0uf, 15KVDC CAPACITOR	CSI	15M2Y0
C14	21011	1	0.01uf, 50VDC MONO-CERAMIC	SPRAGUE	1C10X7R103K050B
CR1		4	30KV, 0.40A DIODE	EDI	RVF-30
CR2		1	S/A CR1		
CR3		1	S/A CR1		
CR4			S/A CR1		
CR5		2	50KV, 2.25A RECTIFIER DIODE	EDI	KHP-50
CR6			S/A CR5		
CR7		1	25KV, 2.25A RECTIFIER DIODE	EDI	KHP-25
F1	22006	1	FUSE, 1.5A TIME DELAY	COOPER	MDL-1.5
F2	22011	1	FUSE, 5A TIME DELAY	COOPER	MDL-5
F3		1	FUSE, 0.25A TIME DELAY	COOPER	MDL-.25
FH1	12001	3	FUSE HOLDER, PANEL MOUNT	LITTLEFUSE	342012A
FH2			S/A FH1		
			S/A FH1		
FL1		1	FILTER, LINE 20A	CORCOM	20VR1
J1		4	CONNECTOR, BNC PANEL MOUNT	KINGS	KC-79-94
J2			S/A J1		
J3			S/A J1		
J4			S/A J1		
J5		3	SOCKET, RELAY 8 PIN OCTAL	P&B	27E122
J6			S/A J5		
J7			S/A J5		
K1		1	CIRCUIT BREAKER, 15A PANEL MT.	HEINEMANN	TX1-P15-U00-WH2
K2		2	RELAY, G. P. DPDT 24VDC COIL	MAGNECRAFT	W250CPX-7
K3			S/A K2		
K4		1	RELAY, DELAY ON MAKE 0-15min	MAGNECRAFT	W211ACPSOX-60
K5		1	RELAY, H. V. DUMP	ROSS	E-60-NC-80
L1		1	CHOKE, CHARGING 5Hy	MAG-CAP	
M1	42023	1	PANEL METER, LED 3.5 DIGIT	SIMPSON	24602
R1		3	10Meg OHM, 10W, 0.1% RESISTOR	CADDOCK	MG810-10M
R2			S/A R1		
R3	24110	1	20K OHMS, .25W, 1% RESISTOR	DALE	RN60C2002
R4			S/A R1		
R5	24025	1	10K OHM, 0.5W, 1% RESISTOR	CGW	RN65D1002FJ
R6		2	20K OHM, 225W, RESISTOR	OHMITE	L225J20K
R7			S/A R6		
R8		1	20K OHM, 100W, RESISTOR	OHMITE	L100J20K
R9		1	150 OHM, 225W, RESISTOR	OHMITE	L225J150
R10		1	75 OHM, 225W, RESISTOR	OHMITE	L225J75R
R11		1	0.1 OHM, 50W, 1% SENSE RESISTOR	CLAROSTAT	CMC-50/0.1R
T1	52012	1	0-120VAC, 10A, VARIAC	STACO	1010
T2		1	POWER TRANSFORMER	MAG-CAP	
T3		1	HEATER TRANSFORMER	SIGNAL	12.8-12
T4		1	1:4 PULSE TRANSFORMER	MAG-CAP	
X1	17002	1	PANEL, 19" RACK, 15.75"H	BUD	SFA-1839
X2		1	ENCLOSURE, 15.75"H x 20.00"D	CCE	BXG610
V1		1	THYRATRON	LITTON	L4915

C. C. E.
CUSTOMER:
TITLE :
BILL NO:

NSWC
T610 THYRATRON GRID PULSER P.S.
MT610

NAME/DATE:
CUSTOMER PO:
CONTRACT NO: N60921-94-C-A345
31-Jan-95

DESIG.	P/N	QTY.	DESCRIPTION	MFR	MFR PART NO.
C1	21009	9	0.01uf, 1KVDC CERAMIC DISK	SPRAGUE	5GAS10
C2			S/A C1		
C3			S/A C1		
C4			S/A C1		
C5	21019	1	20uf, 350VDC ALUM. ELECTROLYTIC	MALLORY	TC65
C6			S/A C1		
C7			S/A C1		
C8	21021	1	100uf, 35VDC ALUM. ELECTROLYTIC	MALLORY	TKR101M1VF11V
C9			S/A C1		
C10			S/A C1		
C11			S/A C1		
C12	21036	1	240pf, 50VDC MICA	CDE	CD10-FD241J03
C13	21035	1	10pf, 50VDC MICA	CDE	CD10-CD100D03
C14		1	5uf, 450VDC ALUM. ELECTROLYTIC	MALLORY	TC70
C15	21002	3	0.1uf, 600VDC POLYPROP.	SPRAGUE	715P10456LD3
C16			S/A C15		
C17			S/A C15		
CR1	31010	1	BRIDGE RECTIFIER, 1KV, 2A	FAGOR	FBP10
CR2	31001	10	DIODE, G/P 1KV (PIV)	MOTOROLA	1N4007
CR3	31020	1	DIODE, ZENER 8.2V (Vz) 0.5W (Pd)	MOTOROLA	1N4738
CR4			S/A CR1		
CR5			S/A CR1		
CR6			S/A CR1		
CR7			S/A CR1		
CR8			S/A CR1		
CR9	31004	1	DIODE, ZENER 4.7V (Vz) 5W (Pd)	MOTOROLA	1N5337B
CR10			S/A CR1		
CR11			S/A CR1		
CR12			S/A CR1		
CR13			S/A CR1		
Q1	32004	5	POWER TRANSISTOR, 40W (Pd)	MOTOROLA	TIP-50
Q2					
Q3					
Q4					
Q5					
R1	24001	5	4.7 OHM, 0.5W CC	A-B	RC20EB
R2	24033	2	270K OHM, 0.5W CC	A-B	RC20EB
R3	24002	2	47 OHM, 0.5W CC	A-B	RC20EB
R4	24086	1	100 OHM, 0.25W CC	A-B	RC07EB
R5	24161	1	8.25K OHM, 0.25W CC	A-B	RC07EB
R6	24091	1	330 OHM, 0.25W MF	DALE	RN60D8251F
R7	24134	1	18.2K OHM, .025W MF	DALE	RN60C18.2K
R8	24092	1	470 OHM, 0.25W CC	A-B	RC07CB
R9	24105	2	150K OHM, 0.25W CC	A-B	RC07CB
R10			NOT USED		
R11	24017	1	1.2K OHM, 0.5W CC	A-B	RC20EB
R12	24118	1	15K OHM, 0.25 CC	A-B	RC07CB
R13	24113	1	1.43K OHM, 0.25W MF	DALE	RN60D1431F
R14	24093	1	1K OHM, 0.25W CC	A-B	RC07CB
R15			S/A R9		
R16			NOT USED		
R17			S/A R2		
R18	24049	1	10 OHM, 1W CC	A-B	RC32GB
R19	24065	1	2.2K OHM, 2W CC	A-B	RC42HB
R20			S/A R1		
R21			S/A R1		
R22	24047	1	10Meg OHM, 0.5W CC	A-B	RC20EB
R23			NOT USED		
R24			S/A R3		
R25			S/A R1		
R26			S/A R1		
T1	52010	1	POWER TRANSFORMER	STANCOR	DSW-220
U1	33004	1	FLOATING V/C REGULATOR	MOTOROLA	MC1466L
VR1	36001	1	MOV VARISTOR, 130VRMS	HARRIS	V130LA20A


C. C. E.
 CUSTOMER: NSWC
 TITLE : T610 THYRATRON GRID PULSER
 BILL NO: MT610

NAME/DATE:
 CUSTOMER PO:
 CONTRACT NO: N60921-94-C-A345
 31-Jan-95


DESIG.	P/N	QTY.	DESCRIPTION	MFR	MFR PART NO.
A1	ST610-2	1	SCHEMATIC		
A2	ST610-3	1	THYRATRON DRIVER BOARD AND TRANSFORMER		
A3	ST610-4	1	POWER SUPPLY GRID PULSER		
C3	21021	2	100 uF 35VDC (VERTI ELECT)	MALLORY	TKR101M1VF11V
C4	S/A C3				
C5	21006	1	0.1uF, 50VDC (MONO CERAMIC)	SPRAGUE	1C20Z5U104M050B
C6	21011	1	0.01uF, 50VDC (MONO CERAMIC)	SPRAGUE	1C20Z5U103M050B
C7	21019	1	20uF, 350VDC (ALUM. ELECT.)	MALLORY	TC65
CR1	31001	1	DIODE, G/P 1KV (PIV)	MOTOROLA	1N4007
CR2	31019	1	ZENER DIODE, 5.1V(Vz), 0.5W (Pd)	MOTOROLA	1N5231B
CR3	31009	1	DIODE, Si/SWIT 100V (PIV)	TEXAS INST.	1N914B
F1	22003	1	FUSE, SLO-BLO, 0.5A	BUSS	MDL-1/2
FH1	12004	1	FUSEHOLDER	LITTLEFUSE	342012A
FL1	23010	1	FILTER, IN-LINE, 1A	CORCOM	1VK1
L1	51001	1	CHOKE, 60mH	ATLAS ENG.	AE11747
Q1	32002	1	TRANSISTOR, PNP, G/P	MOTOROLA	2N3250
R1	24082	1	10 OHM, 0.25W CC	A-B	RC07
R2	24099	1	10K OHM, 0.25W CC	A-B	RC07
R3	24116	1	3.9K OHM, 0.25W CC	A-B	RC07
R4	24165	1	8.2K OHM, 3W WW	DALE	RS-2B
U2	33005	1	REGULATOR, 5V, 0.5A, TO-220	MOTOROLA	78M05
U3	33044	1	F.O. RECIEVER, VERSALINK	H-P	HFBR-2523
U5	31010	1	RECTIFIER, BRIDGE, 1KV, 2A	FAGOR	FBP10
T1		1	PWR XFMR, 120V 0.2A	SIGNAL	PC120-200
T2		1	PWR XFMR, 56V 0.18A	SIGNAL	PC56-180
T3		1	PWR XFMR, 10V 0.44A	SIGNAL	DPC10-440

REF. DESIG.	A2 P/N	QTY.	THYRATRON DRIVER BOARD AND TRANSFORMER DESCRIPTION	MFR	MFR PART NO.
REF	ST610-3	1	THYRATRON DRIVER BOARD AND TRANSFORMER		
REF	CLT610	1	COMPONENT LAYOUT		
REF	PWB16008	1	PC BOARD		
C1			NOT USED		
C2	21002	2	0.1uF 600VDC (POLYPROP)	SPRAGUE	715P10456LD3
C3			S/A C2		
C4	21001	1	0.047uF 600VDC (POLYPROP)	SPRAGUE	715P47356LD3
C5			N/U		
C6	21021	2	100 uF 35VDC (VERTI ELECT)	MALLORY	TKR101M1VF11V
C7			S/A C6		
C8	21006	2	0.1 uF 50VDC (MONO CERAM)	SPRAGUE	1C20Z5U104M050B
C9			S/A C8		
C10	21030	1	0.0068 uF 200VDC (POLYESTER)	SPRAGUE	192P682X9200
C11	21011	2	0.01 uF 50VDC (MONO CERAMIC)	SPRAGUE	1C10X7R103K050B
C12	21034	1	4.7uF 35VDC (TANTALUM)	SPRAGUE	196D475X9035JA1
C13			S/A C11		
C14	21007	1	1.0uF 50VDC (MONO CREAM)	SPRAGUE	2C25Z5U105M050B
C15	21005	1	68pF 1kVDC (CERAMIC DISK)	SPRAGUE	10TCCQ68
C16	21009	1	0.01uF 1kVDC (CERAM DISK)	SPRAGUE	5GAS10
C17	21042	1	12-100pF TRIMMER (MICA)	JOHANSON	9328
C18	21048	1	500PF 10KV CER DISK	SPRAUGE	100GAT50

CR1	31011	8 DIODE, F/REC 600V (PIV)	MOTOROLA	MR826
CR2		S/A CR1		
CR3	31003	1 DIODE, F/REC 600V (PIV)	MOTOROLA	1N4937
CR4		S/A CR1		
CR5		S/A CR1		
CR6	31013	1 SCR 2000 A/usec (di/dt)	AMPEREX	BTW63-800RK
CR7		S/A CR1		
CR8		S/A CR1		
CR9	31005	1 ZENER DIODE, 82V(Vz) 5W(Pd)	MOTOROLA	1N5375
CR10		S/A CR1		
CR11	31001	1 DIODE, G/P 1KV (PIV)	MOTOROLA	1N4007
CR12		NOT USED		
CR13	31009	2 DIODE, Si/SWIT 100V (PIV)	TEXAS INSTR.	1N914
CR14		S/A CR13		
CR15		S/A CR1		
DS1	34002	1 LED PANEL MOUNT, RED	IDI	5100H1
J1		N/U		
J2	14015	3 ISOLATED BNC	KING	KC-79-67
J3		S/A J2		
J4		S/A J2		
J5	14001	1 SHV BULKHEAD RECEPTACLE	KING	1704-1
J5A	14002	1 SHV PLUG	KING	1705-14
L1		NOT USED		
L2		1 COIL, 24T/in L=10.0 uH	CCE	BW1T
Q1	32003	1 NPN HV/HC XSISTOR TO-39	MOTOROLA	2N5682
Q2	32001	2 NPN G/P XISTOR TO-18	MOTOROLA	2N2222
Q3		S/A Q2		
R1		1 100 OHMS 25W WW	OHMITE	L25J100
R2		N/U		
R3	24059	2 4.7 OHMS 2W CC	A-B	RC42
R4		S/A R3		
R5	24073	1 1.2M OHMS 2W CC	A-B	RC42
R6	24026	1 12K OHMS 1/2W CC	A-B	RC20
R7		NOT USED		
R8		NOT USED		
R9	24068	2 47K OHMS 2W CC	A-B	RC42
R10	24001	1 4.7 OHMS 1/2W CC	A-B	RC20
R11		NOT USED		
R12		NOT USED		
R13		NOT USED		
R14	24085	3 100 OHMS 1/4W CC	A-B	RC07
R15	24116	1 3.9K OHMS 1/4W CC	A-B	RC07
R16	24099	2 10K OHMS 1/4W CC	A-B	RC07
R17		S/A R16		
R18	24103	1 47K OHMS 1/4W CC	A-B	RC07
R19	24093	1 1K OHMS 1/4W CC	A-B	RC07
R20	24088	1 150 OHMS 1/4W CC	A-B	RC07
R21		S/A R14		
R22		S/A R14		
R23	24066	1 4.7K OHMS 2W CC	A-B	RC42
R24		S/A R12		
R25	24118	1 15K OHMS 1/4W CC	A-B	RC07
T1	52001	1 PULSE XFMR 1:4.8 2KV	MERZ	AE11458
T2	52004	1 PULSE XFMR 8:1	PULSE ENGR.	PE3016X
T3	52013	1 PULSE XFMR, 1:1	PULSE ENGR.	PE5156X
U1	33005	1 REGULATOR, 5V 500mA TO-220	MOTOROLA	MC78M05CT
U2	33003	1 TIMING CIRCUIT	MOTOROLA	MC1455P1




REV/ISSUES		DATE / APPROV	
LYR	DESCRIPTION	DATE	APPROV
UNLESS OTHERWISE SPECIFIED, ALL DIMENSIONS ARE IN INCHES. METRIC DIMENSIONS ARE IN PARENTHESES. TOLERANCES OF FRACTIONS 3/64 DECIMALS. TOLERANCES OF DECIMALS .X .001 .XX .0005 .XXX .001.			
1. BREAK EDGES 1/64 MAX. 2. DO NOT SCALE THIS DRAWING. 3. DIMENSION TO ANSI Y14.3 1982. 4. MAX ALL MACHINED SURFACES.			
PART NOT TEST ASSY. USED ON APPLICATION			
REFERENCE ONLY			
DRAWN BY: CCR			
APP'D: CCR			
C. C. E., INC.			
TRIGGER GENERATOR			
T-610			
CAGE CODE	DRAWING NO.	REV	
02887	ST610-1	B	
SCALE	WEIGHT	SHEET	OF
		1	1




REFERENCE ONLY	UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN PARENTHESES METRIC DIMS ARE IN PARENTHESES TOLERANCES FOR FRACTIONS ±1/64 TOLERANCES OF DECIMALS X .0001 JACK RUNGOS ±.0015"	DATE DRAWN B.W.V. 11-54 PFRB APPD	C. C. E.
1. BREAK EDGES 1/4" X MAX 2. SURFACES TO BE MACHINED 3. DIMENSIONS TO ANSI Y14.5 1982 4. MAIL ALL MACHINED SURFACES.		SHEET CASE NO. 02687 DRAWING NO. ST610-2 REV A SCALE N/A WEIGHT SHEET 2 OF 5	THYRATRON GRID PULSER
PART NO	NEXT ASSY.	USED ON	APPLICATION

REV	DATE	BY	APP
D	02887	ST610-5	B
C. C. E.			
THYRATRON TRIGGER IN			
TRIGGER RESET			
TRIGGER INTERLOCK			
REV. 1.50 5			



DATE	10/00
REV	DESCRIPTION
1	REV

APPLICATION	REFERENCE ONLY
PART NO	NEXT ASSY
USED ON	
1. MAKE ALL WOODEN SURFACES	
2. DIMENSIONS TO FACE UNLESS NOTED	
3. DO NOT SCALE THIS DRAWING	
4. BREAK EXCES 1/64 MAX	
5. TOLERANCES OF DECIMALS	
6. TOLERANCES OF FRACTIONS 1/16	
7. UNLESS OTHERWISE SPECIFIED	
8. ALL DIMENSIONS ARE IN INCHES	
9. METRIC (MM) ARE IN PARENTHESES	
10. DRAWN	
11. CHECKED	
12. DATE	
13. C. C. E.	
14. TRIGGER PANEL	
15. G610	
16. DRAWING NO.	MTD610-20
17. REV	B
18. SCALE	02887
19. WEIGHT	
20. SHEET OF	



REV	DESCRIPTION	DATE	APPROV

UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES METHOD AND ARE IN PARENTHESES		DRAWN		DATE	
TOLERANCES OF FRACTIONS 16/64		CHECK		APP'D	
TOLERANCES OF DECIMALS		X .001		X .0005	
X .001		X .0005		X .001	
1. BREAK EDGES 1/4" MAX		2. DO NOT SCALE THIS DRAWING		3. DIMENSION TO FACE UNLESS	
4. HIDE ALL UNWORKED SURFACES		CONTRACT/JOB NUMBER		SCALE	
PART NO. NEXT ASSEMBLY USED ON		CASE CODE		WEIGHT	
		02887		SHEET OF	
		DRAWING NO.		REV	
		MTD610-21		B	
		G610			
		C. C. E.			
		TRIGGER PANEL			

